


# HS-20USB USER MANUAL



Copyright 2007  
Cyberpak Company Inc.  
All Rights Reserved

Revision Date: July 2007  
Revision 1.39  
CyberVec Revision 5.67

# Table of Contents

Introduction.....	7
Features.....	7
Manual Organization.....	7
Hardware Reference Manual.....	8
Connector Summary.....	8
Communications.....	8
Introduction.....	8
Communications Configuration Options.....	9
Host USB Port Direct (Additional Attachments via USB Hub).....	9
Host COM Port Direct (Optional RS-232 Multi-Drop).....	10
Host USB Port Direct with Serial Multi-Drop Expansion.....	11
Stand-Alone with Optional RS-232 Multi-Drop.....	11
RS-232 Connector (J402) Pin Definitions.....	12
Power Connector (J501) Pin Definitions .....	12
Motor Control Connector (J201) Pin Definitions.....	13
Expansion Port Connector (J301) Pin Definitions.....	15
Analog and Encoder Interface Connector (J601) Pin Definitions .....	16
High Current Sinking Outputs (J701) Pin Definitions.....	17
Jumper Summary.....	17
CyberVec Reference Manual.....	18
Overview.....	18
CyberVec Dialog Characteristics.....	18
The Basic Programming Environment.....	19
Using the PC to Create and Edit CyberVec Programs.....	20
Downloading Programs from the PC to the HS-20USB.....	21
Programming Environment Advanced Topics.....	21
HS-20USB Addressing.....	22
Status at Power Up.....	23
Special Characters/Character Sequences.....	23
Command Parameters/Arguments.....	23
Immediate vs. Buffered Commands.....	24
Command Documentation Assumptions.....	25
Command Documentation Format.....	25
CyberVec Commands.....	26
Motor and Motion Control Commands.....	26
AN - Accelerate No.....	26
ANG <Mode> - Set Angle Restriction Mode.....	26
AY - Accelerate Yes.....	26
CE <Axis> - Clear Encoder Position Register.....	26
CEP <Axis> <Encoder Scale Factor> <Acceptable Tolerance> - Compare Encoder Position.....	26
CTP <Axis> <Position> <Multiplier> - Compute Target Position.....	26
DN - Decelerate No.....	27
DY - Decelerate Yes.....	27
E0 / E1 - Enable Mode Polarity.....	27
ENC <On/Off> - Encoder Subsystem Enable.....	27

EP <Axis> <Encoder Position> - Set Encoder Position.....	27
GO - Go to Absolute Target Position.....	27
HLT <Axis Mask> - Halt Motor Axis.....	27
JD<a><b> - Joystick Digital Control Mode Begin.....	28
L <Axis> <xxxxxx> - Set Location.....	28
LD <Axis> - Limit Disable.....	28
LE <Axis> - Limit Enable.....	28
NCL - Normally Closed Limits.....	28
NOL - Normally Open Limits.....	28
LM <Mask> - Limit Mask.....	29
LN - Location No.....	29
LY - Location Yes.....	29
MPN <Axis> - Motor Power No.....	29
MPY <Axis> - Motor Power Yes.....	29
QE <Axis> <Scale Factor> - Query Encoder Position Register.....	29
QES <Axis> <Scale Factor> - Query Encoder Scaled.....	29
QL <Axis> - Query Location.....	30
QLS <Axis> <Motor Scale Factor> - Query Location Scaled.....	30
QM <Axis> - Query Motion Status.....	30
R <int> - Rate.....	30
RCN - Run Continuous No.....	30
RCY - Run Continuous Yes.....	30
RN - Ramping No.....	31
RQ <int> - Rate Quick.....	31
RTM <N> - Read Timer.....	32
RY - Ramping Yes.....	32
SAPU <Position> - Set Absolute U Axis Position.....	32
SAPX <Position> - Set Absolute X Axis Position.....	32
SAPY <Position> - Set Absolute Y Axis Position.....	32
SAPZ <Position> - Set Absolute Z Axis Position.....	32
SEP <Axis> <Encoder Scale Factor> - Subtract Encoder Position.....	32
SLC <int> - Set Location Counter .....	32
SLD <arg> - Slow Mode Divisor .....	32
SLN - Slow Mode No.....	32
SLY- Slow Mode Yes.....	32
SME <Axis> <Scale Factor> - Set Motor to Encoder Position.....	33
SR <Ramp ID> - Select Ramp.....	33
STL <Mode> - Stall Detect Enable/Disable.....	33
STM <N> <Type> <Pin> <Time> - Set Timer.....	34
TR1 <data space #> <pin#> - Trigger Pulse Enable Channel #1.....	34
TR2 <data space #> <pin#> - Trigger Pulse Enable Channel #2.....	34
U=<int> - Set Absolute Position Target for U Axis.....	35
Vn <Axis> <Steps> . . . [<Axis> <Steps>] - Vector Relative Move.....	35
WTM <N> <Time> - Wait for Timer.....	35
X=<int> - Set Absolute Position Target for X Axis.....	35
Y=<int> - Set Absolute Position Target for Y Axis.....	35
Z=<int> - Set Absolute Position Target for Z Axis.....	35

Input/Output & Control Panel Interface Commands.....	36
BCD <Type> <Pin> <Switches> - Read BCD.....	36
DCN - Display Cursor No.....	36
DCY - Display Cursor Yes.....	36
DDI <Row> <Col> <Width> <Value> <DPP> - Display Decimal Integer.....	37
DE - Display Enable.....	37
DI <Row> <Col> <Width> <Int> - Display Integer.....	37
DS <Row> <Col> <Width> <String> - Display String.....	37
FCF - Flush Character FIFO .....	37
GCM - Get Character from Matrix Keypad.....	37
GCS - Get Character from Serial Port.....	37
GDM <Row> <Col> <Width> <DPP> - Get Decimal Matrix.....	38
GIM <Row> <Col> <Width> - Get Integer from Matrix Keypad.....	38
GIS - Get Integer from Serial Port.....	38
GSM - Get the Scan Code for a Matrix Keyboard.....	38
IB <Type> <Pin> <Width> - Input Bits.....	38
IIO <Type> <Value> - Initialize for J301 Digital I/O.....	39
OB <Type> <Pin> <Width> <Value> - Output Bits.....	39
OSC <int> - Output Character to Serial Port.....	40
OSD <int> - Output Decimal to Serial Port.....	40
OSI <int>- Output Integer to Serial Port.....	40
OSS "string"- Output String to Serial Port.....	40
OUT <x> - Output Number to Serial Port.....	40
QAX <Analog Channel Address> - Query 8 Bit Analog Channel.....	40
QK - Query Matrix Keyboard.....	40
QSC - Query Serial Count.....	40
RDY- Ready I/O.....	41
Arithmetic & Logic Commands.....	42
ABS <Integer> - Absolute Value.....	42
ADD <Value1> <Value2> - Add two Values.....	42
ADP <Integer> - Add to Pointer.....	42
AND <Integer1> <Integer2> - Logically Bitwise And Two Values.....	42
BIT <Value> <Bit> - Bit Test Instruction.....	42
BRK - Break Out of Program Loop.....	42
BRO <Offset> <Table> - Branch on Offset into Table.....	43
CAL <Prog> - Call Program.....	43
CLO <Offset> <Data Space> - Call with Offset.....	44
COM <Int> - Complement Bits.....	44
DIV <Int1> <Int2>.....	44
DP- Decrement Pointer.....	44
DUP- Duplicate Top Stack Item.....	44
EQ <int1> <int2> - Test for Equality.....	44
FOR <arg1> {loop commands} - FOR Loop Statement.....	44
GT <int1> <int2> - Greater Than Test.....	45
IDV <Numerator> <Denominator> - Signed Integer Divide.....	45
IF arg1 { [optional true clause] ? [optional false clause]} - If Conditional Statement.....	45
IP - Increment Pointer.....	45

LT <int1> <int2> - Less Than.....	45
MUL <int1> <int2> - Multiply.....	46
NEG <int> - Negate.....	46
NXT - NEXT .....	46
OR <int1> <int2> - Logically Bitwise OR.....	46
POP- Pop Pointer.....	46
PUP- Push Pointer.....	46
RET- Return from CAL.....	47
RP - Read Value at Pointer.....	47
RV <var> - Read Variable.....	47
SP <int> - Set Pointer to Program Space.....	47
SUB <int1> <int2> - Subtract.....	47
SUP <integer> - Subtract Pointer.....	47
SWP - Swap.....	47
WHL <arg1> { loop commands} - While Loop.....	47
WP <int> - Write Value to Pointer.....	48
WV <var> <int> - Write Variable.....	48
General/System Commands.....	49
<ESC> - Abort/Interrupt Program.....	49
@<ESC> - GLOBAL ESCAPE .....	49
AB - Abort.....	49
AIc - Acknowledge Immediate.....	50
AKc - Acknowledge Buffered .....	50
AR - Address Read .....	51
CR <Ramp> - Checksum Ramp .....	51
D <Int> - Delay .....	51
DD <Prog> - Data Dump.....	51
DL <Prog> <Count>- Data Load .....	51
DOB - Dump Output Buffer.....	52
DR <Ramp> <Count> - Download Ramp.....	52
EN - Echo No.....	52
EY - Echo Yes.....	52
FL - Flush Buffer .....	52
PC <Prog> - Program Checksum.....	52
PD <Prog> - Program Dump .....	53
PL <Prog> - Program Load.....	53
PO - Pop the Stack.....	53
PU <int> - Push Value onto Stack.....	53
PV <Prog> - Program Verify.....	53
PX <Prog> - Program Execute.....	53
QF - Query Flags.....	54
QI - Query Instruction Count.....	54
QS - Query Sense/Limit Inputs.....	54
QV - Query Version Number .....	55
RES <Area> - Restore RAM.....	55
RST - Reset.....	55
SAV <Area> - Save RAM.....	55

ST - Self Test.....	55
WC - Wait For Commands to Finish.....	56
WOH <Type> <Mask> - Wait On High.....	56
WOL <Type> <Mask> - Wait On Low.....	56
WPH <Type> <Pin> - Wait For a Pin to Go High.....	56
WPL <Type> <Pin> - Wait For a Pin to Go Low.....	57
Internal Commands.....	58
ID - Immediate Disable .....	58
IE - Immediate Enable .....	58
QR - Query Rate.....	58
QT - Query Ramp Table Characteristics .....	58
RD - Rate Down .....	59
RH <int> - Rate Home.....	59
RI <int> - Rate Immediate.....	59
RS <int> - Rate Slew.....	59
RU - Rate Up.....	59
APPENDIX A.....	60
Installation of USB Driver Software on Host PC.....	60

## Introduction

The HS-20USB is a 3.9" x 6.0" circuit board on which has been implemented a 4-axis step motor indexer/controller with USB 2.0 interface. It can control up to 4 step motors via external step and direction driver cards operating in full or half step mode. The HS-20USB, in turn, can be controlled directly from a host PC by downloading commands to it via the USB interface, or it can operate stand-alone by executing a previously downloaded program. In either case -- immediate or stored program execution -- the command set utilized is CyberVec, a powerful, text string-based language which the HS-20USB can interpretively execute and which includes commands for step motor control, digital and sensor I/O, control panel I/O, arithmetic, branching, and looping.

## Features

- 4 axis control via external step and direction / full or half step driver cards
- Can be used with any step and direction interface driver card including CyberPak's own CY-41 and/or CY-42
- Encoder support for each axis
- USB 2.0 interface operating in serial/RS-232 emulation mode
- Auxiliary RS-232 serial port which can be used in place of the USB interface for host PC communication and/or as a means of multi-drop connectivity for up to 7 additional HS-20USB boards
- Module address switch for use in multi-drop configurations
- Embedded CyberVec interpreter
- Direct control from PC (or PLC) via immediate execution of CyberVec commands
- Stand-alone operation via execution of previously downloaded CyberVec program
- Non-volatile FLASH storage for CyberVec programs and parameters
- 8-12 V unregulated or 5V regulated logic supply option
- 12 digital inputs with built-in support for joystick/limit switch control
- 4 8-bit analog inputs
- 8 open drain outputs which can drive relays, solenoids, and other small loads
- Built-in support for a local control panel (10 key keypad, LCD display, thumbwheel)

## Manual Organization


This manual is divided into the following sections:

- Hardware Reference Manual
- CyberVec Reference Manual
- Appendix A - Installation of USB Driver Software on Host PC

# Hardware Reference Manual

## Connector Summary

- USB - J401
- Serial Port – J402
- Power - J501
- Motor Indexing - J201
- Aux I/O - J301
- Encoder – J601
- Solenoid Outputs – J701



## Communications

### Introduction

The USB interface of the HS-20USB operates in serial/RS-232 emulation mode utilizing technology provided by semiconductor manufacturer FTDI ([www.ftdichip.com](http://www.ftdichip.com)). In this approach, an FTDI chip



on the HS-20USB board and FTDI software on the host PC (see Appendix A for installation instructions) cooperate to make the USB link emulate a standard RS-232 connection. Indeed, the FTDI software on the PC end actually creates a "virtual" COM port which can be utilized by any PC application -- such as Hyperterminal -- as if it were a real RS-232 COM port.

As such, it is possible to use Hyperterminal to type CyberVec command strings into the HS-20USB for immediate execution. Alternatively, a PC program written in C or Basic can open a virtual COM port and send CyberVec commands to the HS-20USB for execution. As a third alternative, the CyberPak host utility HSL.EXE ("HS Link") can be used to 1) download a bulk CyberVec program to the HS-20USB for subsequent execution, or 2) upload a CyberVec program from the HS-20USB for backup or editing on the host PC.

If an actual RS-232 COM port is available on the host PC, the auxiliary RS-232 port on the HS-20USB can be interchangeably used in place of the USB port for communications.

When USB communication is used, the serial data converted from the USB link is also mirrored on the auxiliary serial port of the HS-20USB.


With this overview, the following section will detail each of the several possible comm configurations.

## **Communications Configuration Options**


- Host USB Port Direct (Additional Attachments via USB Hub)
- Host COM Port Direct (Optional RS-232 Multi-Drop)
- Host USB Port Direct with Serial Multi-Drop Expansion
- Stand-Alone with Optional RS-232 Multi-Drop

### **Host USB Port Direct (Additional Attachments via USB Hub)**

In cases where there is only one HS-20USB the host interface is as simple as connecting a standard USB cable from the computer to the HS-20USB:




Additional HS-20USB's can be connected using a USB hub or additional USB ports on the computer:




Such a configuration is possible because the FTDI host driver software is able to create multiple virtual COM ports and logically connect each to a specific HS-20USB board based on a unique hardware ID number built into each of its USB interface chips. In the above illustration, for example, a virtual COM1 (which can be used just as if it were a real COM port) might be created and linked logically to the #1 HS-20USB board, a virtual COM2 might be created and linked to the #2 HS-20USB, and so on.

### Host COM Port Direct (Optional RS-232 Multi-Drop)

If the host PC has an actual RS-232 COM port, it can be used to communicate with the HS-20USB via the latter's auxiliary RS-232 port. The RS232 connection is made using the 10 pin header (J402) on the PC board and matching connections with a computer DB9 connector. (A DB9 to IDC10 adapter cable is needed for the RS232 connection to the computer). Additional units may be multi-dropped along this same RS 232 bus. Each HS-20USB must be given a unique address in the range 0 - 7 via its address select switch.




In this configuration, a special (although not expensive) RS-232 multi-drop cable is needed which ties together in parallel the TXD, RXD, and GND pins of each HS-20USB, as shown following:



Please consult CyberPak (800-328-3938) for assistance with multi-drop configurations.


### Host USB Port Direct with Serial Multi-Drop Expansion

The first HS-20USB is connected to the computer with a USB cable. Additional units are connected off the first HS20 via RS-232 multi-drop.



### Stand-Alone with Optional RS-232 Multi-Drop

In this configuration a computer is not needed. The master unit can control slave units via the RS-232 interface. (Consult CyberPak for this configuration.) Of course slave units are not required; a single HS-20USB can operate stand-alone to control up to 4 step motors.



Please consult CyberPak (800-328-3938) for assistance with multi-drop configurations.

## RS-232 Connector (J402) Pin Definitions

RS232 Header and Computer Serial DB9 Pinout

J402	DB-9	Definition
3	2	<b>Master Mode:</b> RxD, <b>Slave Mode:</b> TxD
4	7	RTS (Loop Back to CTS)
5	3	<b>Master Mode:</b> TxD, <b>Slave Mode:</b> RxD
6	8	CTS (Loop Back to RTS)
7,8,9,10	1,4,6,9	N.C.
9	5	GND

A host controller can be configured to use Pins 7 and 8 to verify cable plugged in. To use this serial port you must configure your terminal or PC serial port to match these HS-20USB settings. Select the port to be used and set for 8 data bits, 1 stop bit, no parity, and a baud rate of 19200. The HSL.EXE utility is preset with these attributes.

## Power Connector (J501) Pin Definitions

Pin #	Definition
1	8 -12 V unregulated. at .5 A (or +5 volts regulated using jumper JP501)
2	Ground
3	Not used -- keyed

RS-232 Supply (Isolated)

4	Ground (isolated)
5	- 12 V at 50mA
6	+ 12 V at 50mA

Logic power (and, optionally, RS-232 power) is supplied to the HS-20USB via connector J501. A mating female connector is also provided. Pin 1 is toward the edge of the board.

If jumper JP501 is shorted between pins 2 and 3 (those closest to the U501 7805 5 V regulator), the HS-20USB expects a logic power input of 8-12 V unregulated; this is the factory default setting. If jumper JP501 is shorted between pins 1 and 2, the HS-20USB expects a logic power input of 5V regulated.

### **DANGER**

Severe damage will occur if JP501 set for 5 V regulated input and 8-12 V unregulated supplied instead.

## Motor Control Connector (J201) Pin Definitions

J201 is the HS-20USB motor control interface. It allows the connection of the HS-20USB to any device that uses the standard step and direction interface. Pin 1 is marked by an arrow on the connector. The pin numbers then alternate, pin 1 is first pin top row, pin 2 is first pin bottom row and so on, such that all of the even pins are in one row, odd in the other.

Pin #	Name	Function
1	Step 0	Step pulse for motor 0
2	Direction 0	Direction for motor 0
3	Step 1	Step pulse for motor 1
4	Direction 1	Direction for motor 1
5	Step 2	Step pulse for motor 2
6	Direction 2	Direction for motor 2
7	Step 3	Step pulse for motor 3
8	Direction 3	Direction for motor 3
9	Ground	
10	Enable 3	Enable for motor 3
11	CW Limit 0	Clockwise limit for motor 0
12	CCW Limit 0	Counter clockwise limit for motor 0
13	Index 0	Index/Mark input for motor 0
14	CW Limit 1	Clockwise limit for motor 1
15	CCW Limit 1	Counter clockwise limit for motor 1
16	Index 1	Index/Mark input for motor 1
17	CW Limit 2	Clockwise limit for motor 2
18	CCW Limit 2	Counter clockwise limit for motor 2
19	Index 2	Index/Mark input for motor 2
20	CW Limit 3	Clockwise limit for motor 3
21	CCW Limit 3	Counter clockwise limit for motor 3
22	Index 3	Index/Mark input for motor 3
23	+ 5 V Source	250 mA Max total for all pins
24	Enable 0	Enable for motor 0
25	Enable 1	Enable for motor 1
26	Enable 2	Enable for motor 2

### Signal Definitions

**Enable:** Enable is an active high signal. When this signal is high the motor is enabled. When it is low the motor is disabled. (This can be reversed; see CyberVec E0 and E1 commands.)

**Step:** On the rising edge of the step signal the motor will take a step.

**Direction:** When this signal is high the motor will rotate clockwise and when this signal is low the motor is in counter clockwise rotation mode.

**CW Limit:** When pulled low, this motor input signifies that a limit of travel has been reached in the clockwise direction. If limit checking was enabled this axis will stop and move in the

counter clockwise direction as stated under the limit enable command in the indexer/controller manual. The NCL instruction reverses the definition of this input.

**CCW Limit:** When pulled low, this motor input signifies that a limit of travel has been reached in the counter clockwise direction. If limit checking was enabled this axis will stop and move in the clockwise direction as stated under the limit enable command in the HS-20 indexer/controller manual. The NCL instruction reverses the definition of this input.

Following is a diagram showing how joystick and limit switch inputs could be wired into J201:




Figure 1.10) Joystick & Limit Connection.

It is possible to choose normally closed or normally open axis limit switches. If the former, one MUST take the precaution of 'grounding' (making appear normally closed) any unused inputs for any axis which runs with limits enabled (LE), CCW, CW, or INDEX inputs of connector J201. (See CyberVec NCL (Normally Closed Limits) command.)

If operating with normally closed switches, unused inputs are pulled high on the circuit board, so nothing needs to be done with them

## Expansion Port Connector (J301) Pin Definitions

J301 is a user definable external interface connector. Many of the pins on this connector can be defined as inputs or outputs allowing the use of this connector to interface to many different components. Among other things it can support are 1) a 4 line, 40 character LCD display; 2) a 20 key matrix keypad, and/or up to 16 BCD switch digits. This connector (J301) is a user definable input/output interface. These inputs and outputs are limited to 1 mA source or sink. A very general description of this connector is given. This connector must not be used for long cables. It is intended as an electronic to electronic interface in a very protected environment.

<b>Pin #</b>	<b>Name</b>	<b>Function</b>
1-8	IOA0 - IOA7	Byte definable input or output
9	Ground	
11-18	IOB0 - IOB7	Byte definable input or output
19-21	IN1 - IN3 Input	
22	IOC3	Input
23	+ 5 V	
24-26,10	IOD0 -IOD3	Nibble definable input or output

## Analog and Encoder Interface Connector (J601) Pin Definitions

Pin #	Name	Definition
1	Analog0	Analog input, 8 bit ADC
2	Analog1	Analog input, 8 bit ADC
3	Analog	Analog input, 8 bit ADC
4	Analog	Analog input, 8 bit ADC
5	AnalogV+	Analog Supply/Reference Voltage
6	AnalogGnd	Analog Ground Supply/Reference
7	Encoder0A	Encoder Channel 0, Phase A
8	Encoder0B	Encoder Channel 0, Phase B
9	Encoder0I	Encoder Channel 0, Index
10	+5 Volt	Power Supply Source Voltage
11	Ground	Power Supply Ground
12	Encoder1A	Encoder Channel 1, Phase A
13	Encoder1B	Encoder Channel 1, Phase B
14	Encoder1I	Encoder Channel 1, Index
15	+5 Volt	Power Supply Source Voltage
16	Ground	Power Supply Ground
17	Encoder2A	Encoder Channel 2, Phase A
18	Encoder2B	Encoder Channel 2, Phase B
19	Encoder2I	Encoder Channel 2, Index
20	+5 Volt	Power Supply Source Voltage
21	Ground	Power Supply Ground
22	Encoder3A	Encoder Channel 3, Phase A
23	Encoder3B	Encoder Channel 3, Phase B
24	Encoder3I	Encoder Channel 3, Index
25	+5 Volt	Power Supply Source Voltage
26	Ground	Power Supply Ground

### Signal Definitions

**Analog Inputs:** Analog input signals between 0 and 5 volts are accepted by an 8 bit analog to digital converter producing a single byte result in the range 0-255.

**Encoder Inputs:** The encoder generates two pulse wave forms that are 90 degrees out of phase. These inputs are used to monitor shaft movement and direction. The on board encoder circuit multiplies the encoder's 'line count' by four (4X). This means that if you have a 1000 line per revolution encoder, you will get 4000 counts per revolution. The encoder inputs are compatible with open collector or TTL type encoders.

**Encoder Index:** Many encoders have a signal which produces a pulse each revolution. This signal may be connected to the encoder index pin, however the HS-20USB firmware does not make direct use of this input. You may also wish to use it as a general purpose input.




Encoder Power: The +5 volt Power Supply Source voltage and the Power Supply Ground pins may be used to power the circuit on each encoder.

## High Current Sinking Outputs (J701) Pin Definitions

Pin #	Name	Definition
1	External V+	User's power supply (typically +24V)
2	Output2	Sinking Output
3	Output3	Sinking Output
4	Output4	Sinking Output
5	Output5	Sinking Output
6	Output6	Sinking Output
7	Output7	Sinking Output
8	Output8	Sinking Output
9	Output9	Sinking Output
10	Ground	Return

These outputs may be used with small inductive or resistive loads, such as pneumatic valves and small relays. These outputs are NOT PROTECTED against shorts to the power supply positive. All outputs may conduct at once. The following wiring diagram shows an example of how J701 may be used:



## Jumper Summary

JP #	Name	Definition
501	Logic Pwr Supply	1-2 = 5V regulated; 2-3* = 8-12V unregulated * positions 2 and 3 are closest to the 3 terminal 7805 regulator

# CyberVec Reference Manual

## Overview

CyberVec is a complete, text-based language for controlling the operation of a step motor system. As such, it includes not only motion control commands, but also commands for digital and sensor I/O; control panel I/O; arithmetic and logic; branching and looping; host PC (terminal style) I/O; and program management. In total, the CyberVec language includes more than 150 separate commands.

An interactive CyberVec interpreter forms the core of the HS-20USB firmware. As such, the term "CyberVec" as used herein can refer not only to the CyberVec language, but also to this interpreter -- and, by extension, to the HS-20USB itself. For example, if this manual states that "CyberVec provides 128 separate program 'spaces' numbered 0 through 127", what is really meant is that "the HS-20USB, acting in its capacity as a CyberVec interpreter, provides 128 separate program 'spaces' numbered 0 through 127".

As with the BASIC programming environment, the HS-20USB CyberVec interpreter can execute commands interactively as they are presented via the USB (or RS-232) interface; or, the interpreter can accept a complete CyberVec program and store it in flash memory for subsequent (i.e., upon power-up) execution.

Note also that the CyberVec commands downloaded to the HS-20USB do not have to be entered by a human operator; quite often, for example, they are generated by a C or BASIC language supervisory program running on the host PC .

## CyberVec Dialog Characteristics

The dialog between the host PC and the selected HS-20USB is basically an ASCII, terminal-mode dialog (although, as noted, the host end of the dialog can be generated by a BASIC or C language program rather than a human operator).

Given that you have your PC connected to the HS-20USB via a virtual (see Appendix A) or actual comm port, a program such as HyperTerminal (one of the Windows "accessories") can be used to make your PC emulate a terminal: each character you type on the keyboard is transmitted to the HS-20USB, and each character transmitted by the HS-20USB is displayed on your screen.

If the HS-20USB auxiliary RS-232 port is being used to connect with the PC host, the host COM port must be set to 19200 baud, 8 data bits, 1 start bit, 1 stop bits, and software flow control (i.e., XON [Ctrl-Q] / XOFF [Ctrl-S] ).

The CyberVec interpreter can be switched, via the EY and EN commands, between echo and non-echo mode. The former is more appropriate for the human operator, who needs feedback while typing; the latter is more appropriate when the CyberVec commands are being generated by a C or BASIC program.

The CyberVec dialog is "stream" oriented as opposed to line oriented; in other words, the HS-20USB will, in many cases, act upon a meaningful sequence of characters before it has received a RET character. (The ASCII "RET" key [from the old Teletype "carriage return"] is usually labeled "ENT" or "ENTER" on PC keyboards, and is so referred to elsewhere in this manual.) Likewise, CyberVec will in many cases not output a RET/LINE FEED sequence where one would normally be expected. (See sample dialog below for examples.)

With some exceptions, the CyberVec interpreter is case insensitive, i.e., it shouldn't matter whether commands are sent in upper case or lower case letters.

CyberVec maintains a fairly large input buffer -- 256 characters total. The HS-20USB will automatically transmit an XOFF [Ctrl-S] character if this buffer reaches its "high water" mark of 200 characters, and will automatically transmit an XON [Ctrl-Q] character when CyberVec processing has reduced the number of characters in this buffer to its "low water" mark of 150 characters. The abort commands flush this buffer.

Comments beginning with a semicolon (";") have been appended to many of the command lines shown in the examples below. **These are for instructional purposes only and must not be transmitted to an HS-20USB as it will attempt to interpret them as actual commands.**

## The Basic Programming Environment

The HS-20USB CyberVec interpreter provides 128 separate program "spaces" numbered 0 through 127, each of which is able to store a short CyberVec program of up to 250 total characters. A program in one space can chain to a program in another space, or call it as a subroutine.

CyberVec statements sent to an HS-20USB in interactive terminal mode can be stored in a specified program space via the PL (program load) command. Conversely, the PD (program dump) command will cause the contents of a particular program space to be output in text format by the HS-20USB via the terminal mode link. And, the PX command causes program execution to begin at the specified program space.

Each CyberVec program segment (i.e., the program occupying one program space) must be terminated by a text line consisting of a single ASCII period (hex 2E). (Note that many of CyberVec programming examples shown in this manual are not complete program segments but rather a few consecutive commands extracted from a larger program; hence, they are not terminated with a period.)

As a program is being stored into a particular space, a checksum is computer for it and stored separately. This provides a subsequent method for checking program validity.

All of the above described CyberVec program development and execution takes place in RAM. The SAV 1 command can be then be used to store the complete set of 128 programming spaces to flash memory. Upon power-up, the RAM program spaces are restored automatically from flash. **If program space 0 is then found to contain a valid CyberVec program (as determined by recomputing its checksum and comparing against the stored value), it is automatically executed.** This program will typically perform certain initialization housekeeping, and will then invoke programs stored in other

spaces.

There is no requirement that HS-20USB applications occupy consecutive program spaces -- it is perfectly legal, for example, to have an application that lives in program spaces 0, 1, 2, and 117. The only thing to keep in mind is that if you want your application to auto-start on power up, the initialization segment, as noted above, must reside in program space 0.

Following is a typical dialog 1) to enter a two-line CyberVec program (which simply outputs "HELLO, WORLD!" and then "GOODBYE!"), 2) to verify that the program has been correctly entered by a) having it re-output to the serial port and b) actually executing the program, and 3) to save the program to flash memory. When the power is cycled on the HS-20USB, the program is then executed automatically. User input is shown in **bold face**, and <ENT> indicates the "Enter" key. Keep in mind that the semicolon-delimited comments cannot actually be sent to the HS-20USB:

```
PL 0<ENT>                ; set to enter a program for space 0
OSS "HELLO, WORLD!"<ENT>  ; enter a simple print command
OSS "GOODBYE!"<ENT>       ; enter a second print command
.<ENT>                    ; the program must be terminated by a "."
PD 0<ENT>                 ; enter the cmdnd to "dump" the program 0 space
OSS "HELLO, WORLD!"       ; the program is output by the HS-20USB
OSS "GOODBYE!"
.PX 0<ENT>                ; enter the cmdnd to execute the prog 0 space
HELLO, WORLD!             ; the program is executed by the HS-20USB
GOODBYE!SAV 1<ENT>        ; enter the cmdnd to save pograms to flash
D                          ; HS-20USB outputs a "D" when finished saving

                          ; now cycle power to the HS-20USB

(C)CYBERVEC V5.67EU-PROG128 ; HS-20USB first outputs its "banner"
HELLO, WORLD!              ; it then automatically executes program
GOODBYE!                   ; in program space 0 (if any)
```

## Using the PC to Create and Edit CyberVec Programs

CyberVec programs will quickly reach a size where it is easier to create and edit them on a PC, with the programs then being downloaded to the HS-20USB for test and execution.

Inasmuch as CyberVec is text based, CyberVec programs can be managed as simple text files on the PC, with a separate text file for each CyberVec program space. For example, if you develop your application such that it occupies program spaces 0, 1, 2, and 3, the corresponding PC files could be named "APP.V000", "APP.V001", "APP.V002", and "APP.V003".

**It is critical that these program text files be created and edited with a Notepad-type editor, i.e., an editor which does not introduce non-ASCII formatting codes etc..**

Two other points should be kept in mind as well: 1) the semicolon-delimited comments shown in this manual are for instructional purposes only, and must not be included in the CyberVec program text itself; and 2) each CyberVec program segment must be terminated by a line containing a single period.

Following is the sample program above as it would appear as a PC text file:

```
OSS "HELLO, WORLD!"  
OSS "GOODBYE!"  
.
```

## Downloading Programs from the PC to the HS-20USB

Once the contents of the various HS-20USB program segments have been created as separate PC text files, the "Send Text File" feature of Hyperterminal (under the "Transfer" menu header) can be used to automate the actual download of the program segments to the HS-20USB. (In this mode of operation, Hyperterminal transmits the contents of a text file as if it was being typed rapidly on the keyboard.)

With the assumption that a program segment is to be downloaded to HS-20USB programming space 0, and with the assumption that the program is stored as PC file "APP.V000", the procedure is as follows:

1. While still in normal Hyperterminal interactive mode, type the command "PL 0<ENT"> into the HS-20USB to place it in the state where it is expecting entry of a program segment for program space 0.
2. With your mouse, select the Hyperterminal "Transfer" menu heading, then select "Send Text File" from the pull-down menu.
3. When prompted to do, enter "APP.V000" as the name of the file to be downloaded.

Hyperterminal will rapidly transmit the contents of APP.V000 one character at a time. When it reaches the terminating period, it will return to normal interactive mode. This same period will also signal to the HS-20USB that the complete program segment has been entered, and it, too, will return to normal interactive mode.

The above procedure should then be repeated for each of the other program segments comprising the complete application.

[Note: For very fast PC's, a Hyperterminal parameter setting the delay between each character transmitted might need to be increased.]

## Programming Environment Advanced Topics

In addition to being used for program storage, the program spaces can also be used for the storage of tabular data. This data, like the programs themselves, can be saved in flash via the SAV1 command, and is likewise automatically restored from flash upon power-up.

In addition to program RAM, there are two other RAM areas that can be explicitly saved to flash memory and that are automatically restored from flash during power up: 1) "Ramp" (motor accelerate/decelerate curve) storage, 2) and named variable storage. The commands for saving these to flash memory are, respectively, SAV 2 and SAV 3.

One does not have to depend on a power-up to restore the various RAM areas from flash. This can be

done explicitly with the RES 1, RES 2, and RES 3 commands, which respectively restore program, ramp, and variable RAM.

The SAV and RES commands are typically executed in interactive terminal mode during the software development process. Inasmuch as flash memory supports only a limited number of write cycles (though this number is in the millions), **the SAV command should not be embedded in a CyberVec program loop.**

The CyberVec programming environment also includes a stack along with the typical types of stack operations. Many CyberVec commands return their results on the stack. Prefixing such commands with a "!" character causes the result to be output in text format to the serial/USB port instead of being placed on the stack in binary format.

## HS-20USB Addressing

For those systems containing only a single HS-20USB (i.e., non-multipropped), this manual section may be safely disregarded so long as 1) the HS-20USB is set to address 0; and 2) the HS-20USB is not accidentally de-selected by issuing an "@n" command where "n" is some digit other than "0".

When an HS-20USB first powers up (and assuming that it has not been pre-programmed with a stored CyberVec command sequence), it has no way of knowing whether it is a single HS-20USB directly connected to the host PC (even if USB connected), or merely one of several HS-20USB's multi-dropped via RS-232.

A related factor is that whatever the host PC transmits is simultaneously received by all of the HS-20USB's in the system -- i.e., an HS-20USB has no *inherent* method of knowing whether or not it is being talked to; likewise, everything transmitted by each of the HS-20USB's in the system is received by the PC host -- i.e., the PC host has no *inherent* method of knowing which of the HS-20USB's in the system has sent a given message.

In this environment, it is important to understand the critical role played by the address assigned to each HS-20USB via its address selection switch, and the CyberVec conventions surrounding the use of this address. The following explanation will focus on the typical usage; please consult CyberPak (800-328-3938) for possible variants on this basic scheme.

An HS-20USB reads its address select switch during power-up. Even though the switch has 16 different positions, only address 0 through 7 are currently supported.

If there is only one HS-20USB in the system (i.e., the RS-232 multi-drop capability is not being used), it is typically set for address 0.

If there are several HS-20USB's in the system, each must have a unique address. The directly-connected HS-20USB is typically given address 0, with the others assigned the sequential addresses 1, 2, etc..

**The basic CyberVec convention is that only one HS-20USB at a time has the privilege of engaging**

**in a dialog with the host PC.** At power up, that privilege belongs to the HS-20USB with address 0; it will therefore enable its transmitter and issue a start-up message. Meanwhile, all of the other HS-20USB's in the system (if there are any) will disable their transmitters and enter standby mode. During this initial period, all normal transmissions from the host PC are assumed to be directed to HS-20USB 0. (All of the other HS-20USB's in the system [if there are any] receive these transmissions but simply ignore them.) Likewise, all transmissions received by the host are assumed to have originated from HS-20USB 0.

**Thereafter, the host PC must issue a CyberVec "@n" command (where "n" is an HS-20USB address) in order to select a different dialog partner.** That HS-USB -- which is then said to be "selected" -- will enable its transmitter, and all of the other HS-20USB's will disable theirs and enter standby mode (unless executing a previously-issued CyberVec command or commands). During this period, all normal transmissions from the host PC are assumed to be directed to the newly-selected HS-20USB. (All of the other HS-20USB's in the system receive these transmissions but simply ignore them.) Likewise, all transmissions received by the host are assumed to have originated from the newly-selected HS-20USB.

In some instances, such as the global abort (@ESC), a command sent by the host PC is responded to by all HS-20USB's in the system.

## Status at Power Up

SELECTED HS-20USB	0
ECHO MODE	ON (see EY and EN commands)
RAMP MODE	OFF (see RY and RN commands)
MOTOR POWER	OFF (see MPY & MPN commands)
SELECTED RAMP	0 (internal)
LIMIT CHECKING	OFF
LIMIT MODE	NORMALLY OPEN

## Special Characters/Character Sequences

^	Take command argument data from the stack
!	Output the result of a command to the serial/USB port in text format rather than placing on the stack
%	The number following is hexadecimal
ESC	Abort (stops execution and clears input FIFO) for selected HS-20USB
@ESC	Global abort
@n	Select HS-20USB with address "n" (multi-dropped system)

## Command Parameters/Arguments

Most CyberVec commands require numeric parameters, and these can be provided or specified in several different ways. This is illustrated by the following examples of a command to move Motor 0 100 steps:

v1 0 100	; specifies the distance in decimal
v1 0 %64	; specifies the distance in hexadecimal
v1 0 ^	; specifies that the distance is to be taken from the stack

```

; (where it is assumed that 100 is on the stack)
V1 0 K4      ; specifies distance as contents of variable K4
              ; (which is assumed to be 100)
V1 0 'A      ; specifies distance as ASCII numeric code for "A"

```

## Immediate vs. Buffered Commands

The HS-20USB CyberVec interpreter is built around two interleaved tasks, 1) the "buffered" command processor, and 2) the "immediate" command processor. The terminology here is perhaps misleading in that one would think the "immediate" command processor to be the more time critical. In fact, it is the "buffered" command processor which is the real-time, interrupt-driven task which performs time critical functions such as motion control. It is referred to as the "buffered" command processor because the input to it is queued up for instantaneous, contiguous availability -- like a stream of parts going into an assembly line. The "immediate" command processor, on the other hand, performs non-time critical tasks -- such as terminal I/O -- during whatever time is left over between invocations of the buffered task. Paradoxically, such tasks often seem to be performed immediately because they are not part of the time-critical queue being fed to the buffered processor -- hence the designation "immediate" commands.

CyberVec commands can thus be divided into the "buffered" or "immediate" category, and are so designated in this manual.

With this background, consider the following CyberVec program:

```

RY           ; Set ramp mode on
R 5000       ; set rate to 2000 steps per second
V1 0 10000   ; issue move command
D 2000       ; delay two seconds
OSS "DONE"   ; output the string DONE to the serial port

```

This example probably DOES NOT work the way the programmer intended. The programmer probably wanted the "DONE" string to print 2 seconds after move completion. However, "DONE" is printed immediately after the move is initiated. The reason is that V1 (move) and D (delay) are buffered commands, whereas OSS (output string) is an immediate command -- and the immediate command processor task will probably be able to execute it long before the buffered commands are completed.

To accomplish what the programmer intended, one would merely need to insert a WC (wait for clear) command into the above program, as follows:

```

RY           ; Set ramp mode on
R 5000       ; set rate to 2000 steps per second
V1 0 10000   ; issue move command
D 2000       ; delay two seconds
WC           ; wait for subsystem to finish
OSS "DONE"   ; output the string DONE to the serial port

```

The WC command is an immediate command which waits for completion of the buffered commands.



The following is another (and self-documenting) example of the interaction between buffered and immediate commands.

```
V1 0 10000      ; initiate a 10,000 step movement on Motor 0
; the following two commands generate a result WHILE
; the previous command is being processed:
; read a BCD switch for a move distance, scale the BCD switch input
; assuming it is in thousandths of an inch, and that we have a full step
; 200 steps per revolution motor directly coupled to a 5 threads per inch
; screw to form a move distance for motor #1
BCD %12 1 4      ; read move distance for next move (put on stack)
MUL ^ 4          ; 5 thread per inch screw, convert 4 steps/.001 inch
V1 1 ^          ; move number of steps calculated by MUL instruction
WC              ; wait for subsystem finish
```

## Command Documentation Assumptions

HS-20USB systems can be configured in a great variety of ways. For example, rather than having one encoder per motor, a given axis might be assigned two encoders, one to monitor motor rotation and a second to monitor for shaft slippage somewhere else in the drive train.

This manual makes the following assumptions in documenting CyberVec commands:

- An "Axis" or "Motor" argument will resolve to a value between 0 and 3 specifying one of the 4 HS-20USB axes
- Normal motor/encoder association; i.e., the axis address ("Axis") can be used to refer to the motor and/or the encoder

## Command Documentation Format

The following format will be used to document CyberVec commands:

**AAA [<Arg1>] [<Arg2>] - Command Name**

(Buffered /Immediate [;Beta]) Command description.

where "AAA" is the command code itself, <Arg1> and <Arg2> are arguments (where applicable), and "Beta" indicates a command in the beta stage of implementation. This is followed by a brief command description.

# CyberVec Commands

## Motor and Motion Control Commands

### AN - Accelerate No

(Buffered; Beta) This command disables acceleration for subsequent moves. Use this command to link several vector commands together to create a unique movement profile such as ramping up, then running a distance without ramping down after the final move.

### ANG <Mode> - Set Angle Restriction Mode

(Immediate) This command sets multi-axis 'Vn' motion commands to operate in a specific manner. If Mode evaluates to 0 then each vector component will start and stop at the same time and be completed as a single axis move. If Mode evaluates to 1 then the Vn command will execute a multi-axis component of two or more axes to move in a 45 degree direction, followed by a single axis move to complete the major component. In the case where more than two axes are specified, the greatest number of axes will move together the same number of steps followed by successive similar treatment of the remaining axes.

### AY - Accelerate Yes

(Buffered; Beta) This command enables acceleration for subsequent moves. Use this command to link several vector commands together to create a unique movement profile.

### CE <Axis> - Clear Encoder Position Register

(Immediate) This command sets the encoder position register for the specified axis to zero.

### CEP <Axis> <Encoder Scale Factor> <Acceptable Tolerance> - Compare Encoder Position

(Immediate) This command reads the encoder position for the specified axis, divides it by the scale factor using 24 bit integer math, then determines if the resulting value is within the tolerance specified by the final argument. If the encoder and motor positions match within and equal to the tolerance, a TRUE value is returned to the user data stack, otherwise a FALSE is returned to the stack. Notes: The tolerance is in motor step size units; the location counting function must be enabled (see LY command); and both the encoder and the position counters must have been initialized (see L and SEP commands).

### CTP <Axis> <Position> <Multiplier> - Compute Target Position

(Buffered) This command permits specification of a 24 bit position using the 16 bit integer math of CyberVec. Location tracking must be on. (See also LY, L, SAPX, SAPY, SAPZ, and SAPU commands.) Only a single axis may be moved at a time using this command. The move will start as soon as this command is issued.

## **DN - Decelerate No**

(Buffered) This command disables deceleration for subsequent moves. Use this command to link several vector commands together to create a unique movement profile.

## **DY - Decelerate Yes**

(Buffered) This command enables deceleration for subsequent moves. Use this command to link several vector commands together to create a unique movement profile.

## **E0 / E1 - Enable Mode Polarity**

E0 chooses that the enable bit = 1 energizes the motor driver, and the E1 chooses that the enable bit = 0 energizes the motor. The CY-41 requires E0, and the CY-42 requires E1. This command may be used anywhere, but if it is used as the VERY FIRST TWO CHARACTERS of program zero, then the firmware will look ahead even before the system interpreter is started. It will thus very quickly assert the proper mode, which will lessen or eliminate the chance that a 'clunk' noise will occur in the motor as the system powers up. This command must be used before using the MPY and MPN commands, or they may not work correctly.

## **ENC <On/Off> - Encoder Subsystem Enable**

This command is not required unless stall detect (STL) has been enabled. Off is 0, and On is 1.

## **EP <Axis> <Encoder Position> - Set Encoder Position**

(Immediate) This command forces the encoder position register to the value specified in the argument. This command can be used in place of the CE (clear encoder position) command if the desired initialization value is not zero.

## **GO - Go to Absolute Target Position**

(Immediate) Go to an absolute position target which has been previously been set using the X=, Y=, Z=, or U= commands. As of this version, the moves will be executed one axis at a time and in order by axis address. The FL (flush) command resets all absolute positions to zero.

## **HLT <Axis Mask> - Halt Motor Axis**

(Immediate) Begins stopping the motor(s) specified by the the axis mask as soon as this command is executed. If more than one motor is involved in the current movement and the HLT command is use to halt just one axis, the entire vector will ramp down to the start/stop rate of the major axis; the specified motor will be halted; and then the rest of the motors involved will ramp up again to finish the movement. The axis mask is in the format %hhhh where h represents a digit 0 or 1. You must always specify all digits and you must specify the '%' symbol prior to the argument. Example:

HLT %1010 ; stops motors at addresses 1 and 3

## **JD<a><b> - Joystick Digital Control Mode Begin**

(Immediate) This command initiates joystick-style control (with optional limit switch input) of the pair of axes specified by the hex digits 'a' and 'b' (appended directly to the letters "JD"). It is assumed that these two axes have been interfaced as per the J201 section of the Hardware Reference Manual. A third switch may be connected to the INDEX input of the 'b' axis, which, when closed, causes CyberVec to exit from joystick mode. RCY (run continuous), RN (no ramping), and R (rate) commands are usually issued prior to entering joystick mode. If the system is not in run continuous mode, the joystick will trigger a burst of steps each time a change in the axis switches is detected. If this function is called while the system is in RAMPING mode ( see RY ), then closing a joystick switch will ramp up the axis; likewise, releasing the switch will initiate a ramped stop rather than the normal immediate halt.

## **L <Axis> <xxxxxx> - Set Location**

(Buffered) Sets the internal software location counter for specified axis to xxxxxx, which is a hex ineteger. Currently, the '^' (stack) operator may not be used to specify the hex value.

## **LD <Axis> - Limit Disable**

(Immediate) Disables the limit switch checking function for the specified axis (with the possible consequence that a motor may be left in a permanently stalled condition at the axis limit of travel).

## **LE <Axis> - Limit Enable**

(Immediate) Enables limit switch checking for the specified axis. If an over travel is detected one of two things will happen:

1. During single axis move: Upon the detection of over-travel the motor will stop in non-ramped mode, or ramp down to stop in ramped mode. It will then back up step by step until the limit switch opens and then it will stop.
2. During Multi-axis move: Upon the detection of over-travel the system will stop in non-ramped mode or ramp down to stop in ramped mode. Then the remaining motors (those that haven't yet over-traveled) will continue. When the system has finished the remaining moves the motor that over-traveled will back up step by step until the limit switch opens.

## **NCL - Normally Closed Limits**

(Immediate) It is possible to choose normally closed or normally open axis limit switches. Use of this command specifies normally closed switches. You MUST take the precaution of 'grounding' (making appear normally closed) any unused inputs for any axis which runs with limits enabled (LE), CCW, CW, or INDEX inputs of connector J201.

## **NOL - Normally Open Limits**

(Immediate) This is the normal default configuration. This command needs to be executed only if one had previously issued the NCL command and for some reason decided to revert to normally open

inputs. Unused inputs are normally pulled high at the interface, so nothing needs to be done with them.

### **LM <Mask> - Limit Mask**

(Immediate) This command is used to individually define J201 pins as limit inputs or general purpose inputs. Mask is a 12 bit field where the least significant bit corresponds to J201 pin 11 and the most significant bit corresponds to J201 pin 22. A 0 bit enables the corresponding pin as a limit input, while a 1 bit frees the pin for use as a general input. For example, if you have limit switches connected to J201 pins 11,14,17, and 20 (the four CW limits) and wish to use the remaining pins as general I/O you would issue the following CyberVec command:

```
LM %1B6
```

The default on power up is to enable all limit functions (Limit Mask = %0000).

### **LN - Location No**

(Immediate) This command disables location tracking (see LY).

### **LY - Location Yes**

(Immediate) This command causes CyberVec to keep track of the number of steps each axis 0 to 3 takes in internal registers. This information can be read using the QLn (Query Location) command. This function causes significant processor overhead, thus lowering max achievable performance. Location tracking is normally not needed inasmuch as a well-designed step motor system will consistently move the number of steps specified.

### **MPN <Axis> - Motor Power No**

(Immediate) This command disables power to the specified motor. See E0/E1 commands which must be used prior to MPN/MPY to ensure they work correctly.

### **MPY <Axis> - Motor Power Yes**

(Immediate) This command enables power to the specified motor. This command **MUST** be used, even if you are not using the motor power enable output pin. It sets up an internal mask which dedicates the proper step output pin to step pulse train use. See E0/E1 commands which must be used prior to MPN/MPY to ensure they work correctly.

### **QE <Axis> <Scale Factor> - Query Encoder Position Register**

(Immediate) Read the specified encoder position register and output to the serial port in 24 bit hexadecimal format.

### **QES <Axis> <Scale Factor> - Query Encoder Scaled**

(Immediate) Read the specified encoder position register, divide it by the Encoder Scale Factor using

24 bit integer math, then place the result onto the user stack. Caution: It is the programmers responsibility to choose a scale factor which will ensure that the result will fit the 16 bit integer capacity of the user data stack.

### **QL <Axis> - Query Location**

(Immediate) Read the specified axis location register and output to the serial port in 24 bit hexadecimal format. See also QLS.

### **QLS <Axis> <Motor Scale Factor> - Query Location Scaled**

(Immediate) Read the specified axis location register, divide it by the Motor Scale Factor using 24 bit integer math, then place the result onto the user stack. Caution: It is the programmers responsibility to choose a scale factor which will ensure that the result will fit the 16 bit integer capacity of the user data stack.

### **QM <Axis> - Query Motion Status**

(Immediate) Return TRUE to the stack if specified motor is in motion, FALSE otherwise. Example:

```
QM 2                ; Place TRUE or FALSE on stack
IF ^ {OSS "Motor 2 is moving"} ; Print if TRUE
```

### **R <int> - Rate**

(Buffered) This command sets the stepping rate in steps/second to the value specified by int. All subsequent motion commands will run at this rate. Example:

```
R 4000                ; First Rate
V2 0 1000 1 500       ; First Move of two axes
R 2000                ; Second Rate
V2 1 4000 0 2000      ; Second Move
R 1000                ; Third Rate
V2 0 -3000 1 -3000    ; Third Move
```

### **RCN - Run Continuous No**

(Immediate) This command exits from Run Continuous mode. See RCY (Run Continuous Yes).

### **RCY - Run Continuous Yes**

(Buffered) This command causes CyberVec to run the next vector move command continuously until stopped by a command (either RCN or AB). The termination of the continuous move, however accomplished, terminates run continuous mode. To perform another continuous move you must specify RCY again.

Vectors may be implemented in either ramped or non ramped mode while in Run Continuous mode.

There are two methods for terminating a continuous move. First, you may use the RCN command (Run

Continuous No), which cancels continuous mode at once. However, the command which had been running in continuous mode will not terminate immediately. It will instead finish the complete move as specified in the command. It will then terminate normally, as though run continuous mode had never been specified.

Second, you may use the AB (Abort) instruction. This terminates the move immediately. If ramping had been in progress (vector plus Ramping Yes mode), an abrupt halt rather than ramp down will occur. This may cause the motors to slip in coming to a stop. If this occurs the position counters will no longer be correct due to the missed steps.

One way to get a graceful stop with ramping in run continuous mode is to specify a sequence like the one in the following example:

```

RY          ; ramp yes
RCY         ; run continuous yes
V1 0 500    ; single component vector
...
RCN         ; run continuous no

```

## **RN - Ramping No**

(Buffered) All move commands will execute without using ramping after this command has been executed. Step motors cannot start at high speeds. Therefore ramping must be used to start motors when high speeds are required. Ramping starts the motor slowly and then increases, or ramps up, to the desired rate.

## **RQ <int> - Rate Quick**

(Immediate) This command is identical to the buffered rate command (R) except that it is an immediate command. This command can be used to change the motor rate while the motor is running.

Example: An application requires that the motor be run at two speeds depending on whether an input indicates high speed or low speed. (Note: 'RQ 0' will cause a current move to halt by ramping down with no 'location counter' position loss.)

```

                                ; PROGRAM #1
RCY                            ; Select run continuous mode
RY                             ; Select ramp mode
R 2000                         ; Initially set low speed
V1 0 1000                      ; Doesn't matter how many steps
                                ; since we are in run continuous
PX 2                           ; Now execute program #2
.                              ; end of program segment

                                ; PROGRAM #2
IB 1 26 1                     ; Check port 1, pin 26
                                ; for hi/low speed switch
IF ^ { RQ 4000 PX 2}           ; If input = 1 then speed = 4000 and repeat prog 2
RQ 2000                        ; Otherwise set rate to 2000
PX 2                           ; and repeat program 2
                                ; if input is low
.                              ; end of program segment

```

## **RTM <N> - Read Timer**

Read the timer specified by N (0, 1, or 2) and return the result to the stack. See also STM and WTM for a full description of the Timer Subsystem.

## **RY - Ramping Yes**

(Buffered) All move commands will execute using ramping after this command has been executed.

## **SAPU <Position> - Set Absolute U Axis Position**

## **SAPX <Position> - Set Absolute X Axis Position**

## **SAPY <Position> - Set Absolute Y Axis Position**

## **SAPZ <Position> - Set Absolute Z Axis Position**

This command set an absolute position in support of the X=,Y=,Z=, and U= commands. See also GO, X=, Y=, Z=, and U= commands.

## **SEP <Axis> <Encoder Scale Factor> - Subtract Encoder Position**

(Immediate) The internal encoder register for the specified axis is divided (using 24 bit integer math) by the specified Encoder Scale Factor. This scaled encoder value is then subtracted from the current motor position, and the signed difference is placed onto the user stack. Note: If the result of the subtraction produces a difference result greater than 32767 or less than -32768, an overflow will have occurred, and the result placed onto the user stack will be an ERRONEOUS VALUE. This is quite unlikely when this command is used as intended. Location tracking must be enabled. See also LY, CEP, CE, and QE commands.

## **SLC <int> - Set Location Counter**

(Immediate) This command sets the Location Register to the specified 16 bit integer value. This command allows the current location to be set from a 16 bit integer source such as a variable or the user data stack. This command does not allow the full 24 bit range to be set but is useful for smaller range systems where the value must be modified or restored from the 16 bit user data stack or variable spaces.

## **SLD <arg> - Slow Mode Divisor**

(Immediate) Sets "slow mode" divisor to the value of <arg>, which must be in the range of 0 - 255. (A value of 0 effectively sets the divisor to 256.) This command, however, does not actually initiate slow mode -- see SLY.

## **SLN - Slow Mode No**

(Buffered) Return to normal operation after previously executed SLY command.

## **SLY- Slow Mode Yes**



(Buffered) Enters a mode in which all system timing is divided by the slow mode divisor specified by the SLD instruction. This includes step rates and timing with regard to the delay instruction, but does not affect the special timer subsystem instructions. Example:

```
R 1000      ; set system rate to 1000 steps/sec
SLD 100     ; set divisor to 100
SLY        ; choose slow mode ( 1/100 speed)
V1 0 100    ; move 100 steps at actual rate of 10 step/sec
D 20       ; delay two seconds
SLN        ; resume normal rate mode
```

### **SME <Axis> <Scale Factor> - Set Motor to Encoder Position**

(Immediate) When a loss of position or stall occurs, the encoder will have the correct position, and the motor position will be incorrect. This command resets the absolute motor position register for the specified axis to the absolute position value in the encoder register as scaled via the specified scale factor.

### **SR <Ramp ID> - Select Ramp**

(Buffered) Specifies the ramp (accel/decel curve) to be used for subsequent ramped moves. Ramp ID must be an integer in the range 0 - 15; however, storage for only one internal ramp (0) and two external ramps (10 and 11) has currently been implemented. It is important to re-set the rate when a new ramp table is selected. If the rate is not set following a SR command the following moves will occur at unpredictable speeds since an element of the ramp is used to compute internal parameters to achieve the specified speed.

Example: You require a customized ramp table. You may generate this customized ramp table using the GR.EXE (generate ramp -- not implemented yet) program, which permits you to specify start-stop speed, maximum speed, acceleration, and ramp type. You would then use Hyperterminal to download the ramp to HS-20USB ramp area 10. You could then use the following CyberVec program to test the new ramp parameters:

```
SR 10      ; Select ramp %A (10 D)
R 5000     ; Set rate 5000 (must be
           ; lower or equal to Max ramp
           ; value specified in GR.EXE)
V1 0 30000 ; Move 30,000 steps using new ramp
```

Note: Using a negative parameter for this command has an entirely different effect: it loads the timer prescale value with the absolute value of the specified integer. This shifts the rate and acceleration of a given ramp table. (For example, if the value of the prescaler is divided by 2 the base/top rate and acceleration are doubled.) Example:

```
SR -16     ; Sets the prescale value to 16
```

### **STL <Mode> - Stall Detect Enable/Disable**

This command enables (Mode = 1) or disables (Mode = 0) a low-cost stall detection functionality requiring that each motor shaft be equipped with a 180 degree interrupter that blocks an opto-

interrupter for 50% of each revolution, the output of each such optointerrupter being in turn connected to the corresponding axis index input. This command enables or disables monitoring for all axes in unison. If a stall is detected, bit %80 (hex) ins SysFlags is set (see QF [Query Flags] command); in addition, all axes are brought to a halt (via ramping, if in use). It is necessary for the program to issue a "HLT -1 " instruction before any further movement is possible. Furthermore, if this feature is enabled and then disabled, it is necessary to re-enable encoder tracking by using the ENC command. See HLT and ENC.

### **STM <N> <Type> <Pin> <Time> - Set Timer**

This command activates one of the three (0, 1, or 2) countdown timers maintained by CyberVec. These timers operate with 0.01 second resolution and are capable of automatically causing a specifiable output pin to be "toggled" (changed to the opposite setting) when the countdown reaches 0. N is the timer number; Type is 1 for J201 connector output and 2 for J301 connector output (see IB command); Pin is an integer between 1 and 26 specifying the pin to be toggled; and Time is the countdown value in hundredths of a second. See also RTM and WTM.

### **TR1 <data space #> <pin#> - Trigger Pulse Enable Channel #1**

### **TR2 <data space #> <pin#> - Trigger Pulse Enable Channel #2**

(Buffered) Enable trigger mode using program/data space program. This mode is available with step and direction interface only. This option uses J201, pins 1 - 8 as a trigger output pin. It is up to the programmer to make proper selection and use of the pin#. A vector following this command will toggle the trigger pin on the steps specified in the previously loaded program/data space prog. The steps in the program/data space must be in ascending order; the first out of order step will disable trigger mode, as will the end of a vector.

Example: An application requires an output pulse on step locations 10 and 20 from the origin. This pulse is needed in both directions and the first toggle should occur on the specified step with a second toggle after one additional step. Assuming that we start at zero the code would look as follows.

```
DL 11 4      ; Load space 11 with 4 numbers
10           ; you can control pulse width
11           ; by distance step separation
20           ; Start second pulse at 20
21
DL 12 4      ; Load space 12 with 4 numbers
79           ; These are used going backwards
80           ; So count from start of move
89           ; must properly locate pulses
90
TR2 11 7     ; Use space 11 for triggers out J201 pin 7
V1 0 100     ; going in forward direction
TR2 12 7     ; Use space 12 for triggers out J201 pin 7
V1 0 -100    ; going in reverse direction
```

This sequence will cause a level to be toggled on the 10th and 11th steps and on the 20th and 21st of the first vectors. For the second vector realize that we are starting from 100 instead of from zero. We see that step 10 from zero is step -90 from 100. We only specify positive numbers in a trigger so our location is for this toggle is 90. Using this we can calculate that our points to trigger are 80, 81, 90, and 91. Using this data we will toggle the trigger pin at the same absolute position going in both directions.

### **U=<int> - Set Absolute Position Target for U Axis**

(Immediate) Sets absolute position target for axis 3 to int for subsequent GO command. There must be no space characters embedded in this command. (See also GO, X=, Y=, and Z=.)

### **Vn <Axis> <Steps> ... [<Axis> <Steps>] - Vector Relative Move**

(Buffered) Initiates a vectored move, i.e., a multi-axis move in which the speed of the involved axes is coordinated such that the resultant is a straight line. (For example, rather than moving horizontally in the X direction and then vertically in the Y direction to trace out the two perpendicular legs of a right triangle, the X and Y axes are driven simultaneously so as to trace out the hypotenuse.) Argument n (which must immediately follow the "V") specifies the number of axes involved. Two subsequent arguments are required for each such axis: Axis specifies the axis address (0, 1, 2, or 3), and Steps specifies the number of steps to be moved along that axis. The axes can be specified in any order.

Example: An application must generate a linear motion covering a distance of 750 steps along axis 0, 3,000 steps along axis 1, and 1,500 steps along axis 2, and at a rate of 2,500 steps/second.

```
R 2500                ; set rate
V3 1 3000 2 1500 0 750 ; do specified vector move
```

If the motors are to be run above their start/stop speed (typically about 1,000 steps/second for size 23 motors with low inertia loads), the larger step count(s) must be an even multiple of the smallest step count.

### **WTM <N> <Time> - Wait for Timer**

Loads CyberVec timer N with initial countdown value of Time hundredths of a second, then delays program execution until countdown has reached 0. (See also STM and RTM.)

### **X=<int> - Set Absolute Position Target for X Axis**

(Immediate) Sets absolute position target for axis 0 to int for subsequent GO command. There must be no space characters embedded in this command. (See also GO, U=, Y=, and Z=.)

### **Y=<int> - Set Absolute Position Target for Y Axis**

(Immediate) Sets absolute position target for axis 1 to int for subsequent GO command. There must be no space characters embedded in this command. (See also GO, U=, X=, and Z=.)

### **Z=<int> - Set Absolute Position Target for Z Axis**

(Immediate) Sets absolute position target for axis 2 to int for subsequent GO command. There must be no space characters embedded in this command. (See also GO, U=, X=, and Y=.)

## Input/Output & Control Panel Interface Commands

This section contains commands that are used to control input/output and specialized commands for working with the control panel interface. Using these commands it is possible to read and write to the many I/O ports, write a string to the display, or read a matrix keyboard. Some of these commands are specific to a particular type of device. CyberVec supports device drivers for various types of displays, keyboards, and BCD interface schemes. Some of these have evolved due to a direct request from a particular customer. We can most likely add a hardware driver to interface to the device of your choice for a small fee. We will maintain application notes to describe supported devices. Ask! The keyboard matrix display subsystem uses a scan code to character conversion table. You may require customization of this table to match your keyboard overlay. An application note is available describing the BCD interface.

### BCD <Type> <Pin> <Switches> - Read BCD

(Immediate) Reads 4-bit BCD thumbwheel switch(es) via HS-20USB digital interface.

<Type> is an integer representing the location and arrangement of the BCD switches. Current values are:

1	will read direct interface BCD switch(es) on J201
17 (%11)	Uses multiplexed switches on J201
18 (%12)	Uses multiplexed switches on J301

Type 1 is practical for only 2 - 3 digits. Types 17 or 18 can support up to 16 BCD switch digits. It is possible to support more (256) with simple outboard hardware. Contact factory if you require more than 16 BCD switches.

<Pin> is the pin address (1 - 26) of the least significant bit of the least significant digit to be read. BCD always uses the lowest numbered switch as the least significant digit.

<Switches> is the number of BCD switches to be read expressed as an integer.

Example: It is required to read four BCD switches starting at pin location 1 and then to move axis zero the number of steps specified by these switches.

```
BCD %12 1 4      ; Read 4 BCD switches
                  ; Result goes on stack
v1 0 ^           ; Move axis 0 the distance from BCD switches
```

### DCN - Display Cursor No

(Immediate) Turn off the blinking display cursor for the LCD display.

### DCY - Display Cursor Yes

(Immediate) Turn on the blinking display cursor for the LCD display.

### **DDI <Row> <Col> <Width> <Value> <DPP> - Display Decimal Integer**

(Immediate) Displays integer value on LCD display in pseudo floating point format, where Row specifies the display row number (0 = top, 1= bottom); Col specifies the starting column number (0 - 15); Width specifies the number of consecutive cells to be cleared starting at this position prior to updating the display; Value is the integer value to be displayed; and DPP is the decimal point position from the right. For example, to display "1.000" in the upper left corner while clearing the entire top row:

```
DDI 0 0 16 1000 3
```

### **DE - Display Enable**

(Immediate) This command must be executed to initialize the LCD display.

### **DI <Row> <Col> <Width> <Int> - Display Integer**

(Immediate) Displays integer value on LCD, display, where Row specifies the display row number (0 = top, 1= bottom); Col specifies the starting column number (0 - 15); Width specifies the number of consecutive cells to be cleared starting at this position prior to updating the display; and Int is the value to be displayed.

### **DS <Row> <Col> <Width> <String> - Display String**

(Immediate) Displays string on LCD display, where Row specifies the display row number (0 = top, 1= bottom); Col specifies the starting column number (0 - 15); Width specifies the number of consecutive cells to be cleared starting at this position prior to updating the display; and String is the text to be displayed. If String has fewer characters than the field width as specified by Width, String must be terminated by a <RET> character. For example, to display "HELLO" in the upper left corner:

```
DS 0 0 5 "HELLO"
```

### **FCF - Flush Character FIFO**

(Immediate) Flushes all characters from the serial/USB input character FIFO (first in/first out) buffer. The HS-20USB can issue this command to clear spurious or obsolete characters from the buffer before continuing to receive characters from the host PC. (See GCS and GIS commands.)

### **GCM - Get Character from Matrix Keypad**

(Immediate) Returns next character input from matrix keypad using the scan conversion table.

### **GCS - Get Character from Serial Port**

(Immediate) Returns the next byte available from the serial/USB input data stream.

## **GDM <Row> <Col> <Width> <DPP> - Get Decimal Matrix**

(Immediate) Reads integer in pseudo decimal format from matrix keypad and outputs on LCD display as it is being entered, where Row specifies the display row number (0 = top, 1= bottom); Col specifies the starting column number (0 - 15); Width specifies the number of consecutive cells to be cleared starting at this position prior to updating the display; and DPP specifies the assumed decimal point position. For example, if DPP is set to 3, operator inputs of 1, 1.0, 1.00, and 1.000 will cause the same integer value of 1000 to be returned to CyberVec.

## **GIM <Row> <Col> <Width> - Get Integer from Matrix Keypad**

(Immediate) Reads integer from a matrix keypad and outputs on LCD display as it is being entered, where Row specifies the display row number (0 = top, 1= bottom); Col specifies the starting column number (0 - 15); and Width specifies the number of consecutive cells to be cleared starting at this position prior to updating the display. Integer input must be terminated by a non-digit key.

## **GIS - Get Integer from Serial Port**

(Immediate) Returns the integer value assembled from the next available serial/USB input data stream.

## **GSM - Get the Scan Code for a Matrix Keyboard**

(Immediate) Returns the raw scan code for next pressed key on a matrix keyboard. This code represents the location of the key in terms of row and column numbers, with the row in the high nibble and the column in the low nibble.

## **IB <Type> <Pin> <Width> - Input Bits**

(Immediate) Reads bit field from digital inputs.

<Type> is an integer specifying the connector or method of reading connector:

1	J201 connector
2	J301 connector
4	HS-20E J701 high current outputs (can read back output state)
%11	J201 connector (custom multiplexed scheme)
%12	J301 connector (custom multiplexed scheme, see BCD application note)

<Pin> is the pin address (1 - 26) of the least significant bit of the bit field.

<Width> is the width of the bit field (8 max)

The specified bits are read, converted to an 8 bit integer value, and stored on the stack.

Example: Your application has a requirement for a single simple BCD switch. You choose to connect the switch to J301, using input pins 15 through 18. You connect the BCD common terminal to J301 pin 9, and the BCD data bits to 15, 16, 17,18 in ascending bit order. Your program must read this switch and use the result to produce that number of reciprocating movements on one axis.

```

IB 2,15,4    ; read the BCD switch as an integer (value is put on stack)
FOR ^ {      ; use the value read (off the stack) for loop count
V1 0 3000    ; move axis forward 3000 steps
V1 0 -3000   ; move axis backward 3000 steps
}            ; repeat until count exhausted

```

## **IIO <Type> <Value> - Initialize for J301 Digital I/O**

(Immediate) Initializes logic associated with connector J301 for digital I/O. Certain of the pins can be reprogrammed to act as inputs or output. Caution: Some application features require that the IO is committed to particular modes in order to support the application. Examples of this are BCD switches, the LCD display, and the matrix keyboard.

<Type> is an integer specifying the connector or method of reading connector:

2        J301 connector (only legal value for this command)

<Value> specified the resulting I/O configuration of J301 pins:

```

%81 = (1-8) output, (11-18) output, (24-26) & 10 output.
%83 = (1-8) output, (11-18) input, (24-26) & 10 output.
%89 = (1-8) output, (11-18) output, (24-26) & 10 input.
%8B = (1-8) output, (11-18) input, (24-26) & 10 input.
%91 = (1-8) input, (11-18) output, (24-26) & 10 output.
%93 = (1-8) input, (11-18) input, (24-26) & 10 output.
%99 = (1-8) input, (11-18) output, (24-26) & 10 input
%9B = (1-8) input, (11-18) input, (24-26) & 10 input

```

All other values are illegal!

## **OB <Type> <Pin> <Width> <Value> - Output Bits**

(Immediate) Writes bit field to digital outputs.

<Type> is an integer specifying the connector.

```

1        J201
2        J301
4        J701

```

<Pin> is the starting pin address (1 - 26) of the target set

For J201, there are 3 available "groups" of output pins: 1-8; 10; and 24-26. For J301 there are 4 available "groups" of pins (which must have been previously conditioned via the IIO command): 1-8; 10; 11-18; and 24-26. For J701 there is one available "group" of pins: 2-9.

For all three of these connectors, **the set of target output pins must fall within one "group"**.

<Width> is the width of the bit field (8 max)

### **OSC <int> - Output Character to Serial Port**

(Immediate) Outputs least significant 8 bits of <int> to serial/USB port as a single character.

Examples:

```
OSC %D      ; output carriage return character
OSC %A      ; output linefeed character
```

### **OSD <int> - Output Decimal to Serial Port**

(Immediate) Converts <int> to decimal character format and outputs to serial/USB port.

### **OSI <int>- Output Integer to Serial Port**

(Immediate) Converts <int> to hex character format and outputs to serial/USB port.

### **OSS "string"- Output String to Serial Port**

(Immediate) Outputs the characters bracketed by double quote marks to the serial/USB port.

Example:

```
oss "Hello world!"
```

### **OUT <x> - Output Number to Serial Port**

(Immediate) Outputs hex value <x> to the serial/USB port. The number can be an immediate value or from the stack. The following example reads from a 5 digit BCD switch and then sends the value to the serial port:

```
BCD 4,5      ; Put number on stack
OUT ^        ; Output BCD to serial port
```

### **QAX <Analog Channel Address> - Query 8 Bit Analog Channel**

(Immediate) Reads one of the four analog input channels of the HS-20USB. The channel address must be in the range 0-3. The 8 bit unsigned result between 0 and 255 is placed onto the user data stack.

### **QK - Query Matrix Keyboard**

(Immediate) Put a TRUE or FALSE value on the stack depending on whether a key is pressed at the time of execution of this command. Example:

```
QK           ; test to see if key pressed
IF ^ { CAL 11 } ; if yes branch to user options
```

### **QSC - Query Serial Count**

(Buffered) This command returns the number of characters that are present in the serial/USB input



buffer to the data stack. It performs this operation without taking the characters out or looking at them.

### **RDY- Ready I/O**

(Immediate) Enables all I/O's once they have been conditioned via specific commands. (See IIO.)

## Arithmetic & Logic Commands

### **ABS <Integer> - Absolute Value**

(Immediate) This command converts the Integer to a positive number if it was a negative number, and does no conversion if it was a positive number. In both cases the resulting positive number is placed onto the stack.

### **ADD <Value1> <Value2> - Add two Values**

(Immediate) This command adds two 16 bit values and places the result on the stack. The values can be specified individually or from the stack. The individual numbers and the result must be in the range of %FFFF - %0000 (65535 - 0).

### **ADP <Integer> - Add to Pointer**

(Immediate) Add the offset value specified by integer to the pointer. Use this command to help index into data tables. (See also RP, WP, SP, and SUP.)

### **AND <Integer1> <Integer2> - Logically Bitwise And Two Values**

(Immediate) This command ands two 16 bit integers in a bitwise logical operation and places the result onto the stack. Example: Assume that the variable 'B7' contains %4C81 and the following instruction is performed:

```
AND B7 %FF00
```

The value %4C00 is left on the stack.

### **BIT <Value> <Bit> - Bit Test Instruction**

(Immediate) This command tests the bit specified by B in Value and returns to the stack TRUE if the bit is 1, and FALSE if the bit is 0. Bit must be between 0 and 15. This command must be terminated. Example:

```
bit A6 3
```

would return TRUE if the bit at %08 is set (i.e., 1000).

### **BRK - Break Out of Program Loop**

(Immediate) This command is similar to the C language "break" statement in that it causes exit from a loop. This command only works with loop-type instructions such as FOR and WHL. It breaks out of nested IF statements, and even nested calls, until it finds a FOR or WHL loop, and then executes the first command after the close curly brace of that loop.

Example 1: The goal is to exit a loop when a pin goes high:

```

FOR 100 {                ; 100 count loop
IB 1 11 1                ; read stop pin
EQ ^ 1                   ; test for pin value
IF ^ { BRK }              ; if pin 11 is high then exit for loop
CAL 2                    ; call processing instruction
}                          ; end of WHL loop
OSS "Outside of loop"    ; outside of for loop

```

The FOR loop will continue for 100 cycles or until pin 11 goes high. Upon pin 11 being high when tested the BRK command is executed and all commands up to the closing ‘}’ are skipped and the for loop is exited with OSS being the next command executed.

Example 1: Multiple CAL and IF instructions do not affect result of BRK:

```

; "Program 1"
FOR 100 {                ; outside loop
OSS "Outside Loop"      ; display message when we pass here
OSC %D                  ; force a line feed
CAL 2                   ; call program 2
}                        ; end of FOR 100 loop
OSS "Finished" .        ; indicate finished with program
.                        ; end of program space/segment

; "Program 2" called from above
IB 1 11 1                ; read J201 pin 11 one bit only
EQ ^ 1                   ; see if pin 11 was high
IF ^ {                   ; if pin 11 check pin 15
    IB 1 15 1            ; read pin 15
    EQ ^ 1                ; see if pin 15 is high
    IF ^ { BRK }          ; if pin 15 is high break out of for loop
}                          ; end of pin 11 IF Statement
OSS "Inside called Program" ; display
RET                      ; return to caller
.                        ; end of program space/segment

```

This command may not be used outside a control loop structure, and is generally used in conjunction with an IF statement as shown in the example below:

```

WHL 1
{                          ; this symbol establishes body of while loop
QM 1                      ; if motion
COM ^                      ; change to if NO motion
IF ^ { BRK }               ; Break if no motion
}
OSS "Motion has stopped"

```

### **BRO <Offset> <Table> - Branch on Offset into Table**

(Immediate) The first parameter represents an offset into the table in a data area specified by the second parameter. Up to 100 values can be stored in the table. One use for this is to BRO having the offset value come from the matrix keypad, and the offset values stored in the data area table represent program numbers. A key can then branch directly to its support program.

### **CAL <Prog> - Call Program**

(Immediate) Where <Prog> is an integer specifying the program number to execute. The program called will normally have a RET instruction at its end, and when the called program executes the return instruction, execution will continue with the instruction following the call.

### **CLO <Offset> <Data Space - Call with Offset**

(Immediate) This command is similar to BRO but expects the destination program -- found at Offset into data space -- to be terminated with a return. See BRO.

### **COM <Int> - Complement Bits**

(Immediate) Performs a ones complement operation (all zero bits are changed to 1 bits, and all 1 bits are changed to zero bits) on Int, with the result placed on the stack.

### **DIV <Int1> <Int2**

(Immediate) Performs unsigned divide Int1 / Int2 and places result on the stack. (See also IDV.)

### **DP- Decrement Pointer**

(Immediate) Decrement the user data pointer by one element, to point to the previous element.

### **DUP- Duplicate Top Stack Item**

(Immediate) This command duplicates the top item on the stack, with the original value being pushed one level deeper.

Example: It is required to read five BCD switches starting at address four. Motor 1 is then to be moved this number of steps clockwise. After a 5 second delay motor 1 is to be moved this same distance counter clockwise.

```
BCD 4 4      ; Read BCD switches
DUP          ; Duplicate number
V1 1 ^      ; Move specified distance CW
D5000       ; Delay for 5 seconds
NEG ^       ; Make distance negative
V1 1 ^      ; Move specified distance CCW
```

### **EQ <int1> <int2> - Test for Equality**

(Immediate) Where int1 and int2 are the values to be compared. This command compares its two arguments and returns a TRUE to the stack if they are equal or a FALSE to the stack if they are not equal. Using the stack operator removes the compared values from the stack; these values are not saved and are therefore lost following the EQ command. See IF command for example.

### **FOR <arg1> {loop commands} - FOR Loop Statement**

(Immediate) The commands bracketed by curly braces will be executed the number of times specified

by the iteration count parameter arg1. Zero skips over the loop commands without executing any of them. The FOR loop may be nested. Example: Reciprocate a motor axis 10 times:

```
FOR 10      {      ; use value from BCD switch for iteration count
V1 0 1000   ; move motor forward
V1 0 -1000  ; move motor backward
}
```

See also BRK and RET.

### **GT <int1> <int2> - Greater Than Test**

(Immediate) Where int1 and int2 can come from the stack or be immediate values. TRUE is returned if int1 is greater than int2, otherwise FALSE is returned. Example: Execute a move only if a BCD switch value is greater than 100:

```
BCD 4,4      ; Get BCD value
GT ^ 100     ; Is it less than 100
IF ^ { V1 0 1000 } ; If TRUE move
```

### **IDV <Numerator> <Denominator> - Signed Integer Divide**

(Immediate) Where the operation int1 divided by int2 is performed (int1/int2), and the result of this operation is placed on the user data stack. NOTE: This is a signed divide. See also DIV.

### **IF arg1 { [optional true clause] ? [optional false clause]} - If Conditional Statement**

(Immediate) Where arg1 is a Boolean value of either TRUE (not zero) or FALSE (zero). The curly braces { } contain the instructions to execute arg1 equals TRUE, and/or an optional else clause ( ? ). If arg is TRUE then the instructions contained after the open curly brace ‘{’ but before the ‘?’ are executed. If arg1 is FALSE then the instructions after the ‘?’ up to the close curly brace is executed. The IF instruction can be nested up to the limit of the control stack.

Example: A programmer wants to read four bits and test to see if they match a certain test value. If it matches he wants to branch to one routine and if it doesn't he wants to branch to a different routine. The four bits start at bit location 2 and the test pattern is 1011.

```
IB 1 2 4      ; Read four bits and put on stack
EQ ^ %B       ; Test bits read with %0B (1011)
IF ^ {PX 2 ? PX 3 } ; If true execute program area 2
                ; If false execute program area 3
```

### **IP - Increment Pointer**

(Immediate) Increment the data pointer such that it will point to the next data value present in the data list. See also DP, SP, RP, and WP.

### **LT <int1> <int2> - Less Than**

(Immediate) Where int1 and int2 can come from the stack or be immediate values. TRUE is returned if

arg1 is less than arg2, otherwise FALSE is returned. Example: Execute a move only if a BCD switch value is less than 100:

```
BCD 4,4          ; Get BCD value
LT ^ 100         ; Is it less than 100
IF ^ { v1 0 1000 } ; If TRUE move
```

### **MUL <int1> <int2> - Multiply**

(Immediate) Where int1 and int2 are the numbers to be multiplied, the result is left on the stack. The result of the multiplication must be within the range of 16 bit numbers (%0000 to %FFFF or 0 to 65535 DEC).

Example: In a cutoff application a lead screw is used which has 5 threads per inch. The step motor is driven in full step mode with 200 steps per revolution. Each step in this system is .00025 inch, or 4 steps per 1/1000 of an inch. It is decided to have the operator enter the position of a stop using .001 inch units.

```
GIM 1 8 4        ; Get operator supplied coordinate
                  ; off matrix keyboard
MUL ^ 4           ; Compute number of steps
X= ^             ; Setup axis to position
GO               ; Move to absolute target position
```

### **NEG <int> - Negate**

(Immediate) Command negates arg1 (using twos complement arithmetic) and puts the resulting value on the stack. For example, the NEG function of 100 is -100. See DUP instruction for usage example.

### **NXT - NEXT**

(Immediate; Obsolete) Close FOR loop. PLEASE DO NOT USE THE FOR-NXT CONSTRUCTION. Instead use the curly brace construction. The FOR/NXT construction can not be nested.

### **OR <int1> <int2> - Logically Bitwise OR**

(Immediate) Bitwise OR int1 and int2 and place the result onto the stack. See AND for example.

### **POP- Pop Pointer**

(Immediate) Recovers data stack to the pointer. See PUP or example.

### **PUP- Push Pointer**

(Immediate) Pushes the contents of the pointer register onto the data stack. Example:

```
PUP              ; push the pointer onto the stack
ADD ^ 4          ; add an offset of 4 to the pointer
POP              ; pop the new offset pointer
```

Caution: Always keep track of your pushes and pops. See also RP, WP, IP, DP, SP, & POP.

### **RET- Return from CAL**

(Immediate) This command returns to the command after the previous CAL. Example:

```
; IN PROGRAM 2
CAL 9                ; call program 9
OSS "Has returned"    ; this executes after program 9 finishes

; PROGRAM 9
OSS "Program 9"       ; hello from program 9
RET                  ; returns to program 2 (or whoever called)
.                    ; end of program 9
```

### **RP - Read Value at Pointer**

(Immediate) Read value at pointer and place it onto the stack. See also WP, IP, DP, SP, PUP, and POP.

### **RV <var> - Read Variable**

(Command) This command reads a value from a variable location. Variable locations are labeled (A0-A7) ... (Z0-Z7) for a total of 208 integer storage locations.

### **SP <int> - Set Pointer to Program Space**

(Immediate) Set pointer to base of a data area specified by int, which must be a legal program/data area number. See also WP, IP, DP, RP, PUP, and POP.

### **SUB <int1> <int2> - Subtract**

(Immediate) This command subtracts int2 from int1 and places the result on the stack.

### **SUP <integer> - Subtract Pointer**

(Immediate) This command subtracts the integer argument value from the pointer. Use for indexing into data tables. See also RP, WP, SP, and ADP.

### **SWP - Swap**

(Immediate) This command swaps (exchanges position) of the two top values on the stack.

### **WHL <arg1> { loop commands} - While Loop**

(Immediate) The integer arg1 is evaluated each time through the loop. If the argument is TRUE the commands contained in the curly braces are executed. If the argument is FALSE the loop is exited at the close curly brace. The WHL loop can be nested.

Example1: A programmer wants to call a processing routine until a bit goes low:

```
IB 1 2 1      ; Read bit and put on stack
WHL ^ {       ; while pin is high loop
CAL 2         ; call processing instruction
IB 1 2 1      ; read pin to test
}             ; end of WHL loop
```

Example 2: Exit when pin reaches 1 state:

```
WHL 1 {       ; while TRUE (endless loop)
IB 1 2 1      ; read pin to test
IF ^ { RET }  ; return from this program back to caller
              ; use BRK in place of RET if you want to exit loop only
}             ; end of WHL loop
```

### **WP <int> - Write Value to Pointer**

(Immediate) Write the value specified by <int> to the current position of the pointer. See also RP, IP, DP, and SP.

### **WV <var> <int> - Write Variable**

(Immediate) This command writes a value to a variable location. Variable locations are labeled (A0-A7) ... (Z0-Z7) for a total of 208 integer storage locations.



## General/System Commands

### <ESC> - Abort/Interrupt Program

The Escape character (27 or '1B' hex) is a special single character command which does a program abort and partial reset of CyberVec. Unlike other commands, ESC may be sent to CyberVec at any time, even in the middle of another command. Any partial command will be erased as will any commands waiting in the instruction buffer. Additionally the ESC forces any motion to be halted, including the MOVE-OUT portion of a limit switch action. This means that you will have to reset the limit enable (LE) instruction for each axis in order to resume after your program halts.

The escape character stops motion and re-synchronizes communications. The following states/variables are affected:

- System stack is reset.
- Control data stack is reset.
- User data stack is reset.
- Character fifo's ( input & output ) are cleared.
- Run continuous mode is canceled.
- Limits are disabled.
- Any executing motion instruction is ABORTED.
- Active Motor Flags are Cleared.
- System interrupts are ( COMM, MOTION ) enabled.
- Program mode is canceled.
- IF\_SKIP\_BIT is cleared. ( used in skipping IF false instructions)
- Trigger output functions disabled.
- Slow Mode is Disabled.
- Step rate timer is restored.

All other System settings are unaffected by this control character. See also @ESC, AB, and FL.

**DO NOT USE THIS COMMAND AS YOUR SAFETY EMERGENCY STOP**, but instead kill power to the motors via a reliable hardware scheme.

### @<ESC> - GLOBAL ESCAPE

Sending this two character sequence will abort all user programs running on all HS-20 indexers on the network. See ESC above.

**DO NOT USE THIS COMMAND AS YOUR SAFETY EMERGENCY STOP**, but instead kill power to the motors via a reliable hardware scheme.

### AB - Abort

(Immediate) This command aborts the command in progress. If the instruction FIFO is empty (maybe due to a previously issued flush command [FL]), all activity will halt. Otherwise the next instruction in

the instruction FIFO will be executed. Caution: If a ramping command is under execution, steps will be lost, as a non-graceful (not ramped down) halt will occur.

Example: The HS-20USB is being used in a system that provides the operator with a non-emergency stop button. The Control program accomplishes this stop by executing the following command sequence:

```
FL    ; Flush Buffer
AB    ; Abort Current Command
```

This sequence of commands flushes the buffer, erasing the commands within, and aborts the current command bringing the system to a stop.

**DO NOT USE THIS COMMAND AS YOUR SAFETY EMERGENCY STOP**, but instead kill power to the motors via a reliable hardware scheme.

### **AIc - Acknowledge Immediate**

(Immediate) Transmit character "c" to HS-20USB serial/USB port. (Equivalent to an OSS command with a single character string.) There is a buffered version of this command (see AKc), the two of which can be used in combination to monitor the progress of buffered motion commands. Example:

```
v2 1 2000 0 500      ; First move (buffered)
v1 0 800             ; Second move (buffered)
v3 1 -2000 0 1000 2 500 ; Third move (buffered)
AIR                 ; HS-20USB will transmit "r" to indicate it has received
buffered move commands
AKd                 ; HS-20USB will transmit "d" to indicate it has completed
buffered moves
```

### **AKc - Acknowledge Buffered**

(Buffered) Transmit character "c" to HS-20USB serial/USB port. This is the buffered version of the AIc command. This command can be used to signal the host when a series of buffered moves is completed, or to construct one's own protocol.

Example 1: You have a program that sends commands from a text file. It sends commands faster than they can be executed and the buffer overflows. To correct this problem you must change your program to wait for a specified signal before sending the next command:

```
v2 0 2000 1 1000 ; Initiate buffered move
AKd              ; HS-20USB transmits "d" when buffered move done
```

Example 2: An application requires the system to move an X-Y table at a 45 degree angle. Upon completion of this move a pneumatic valve must be opened and the X-Y table must immediately reverse the 45° angle:

```
v2 0 1000 1 1000      ; Move at 45°
AKa                   ; Acknowledge
v2 0 -1000 1 -1000     ; Reverse 45°
```

The commands are sent to the HS-20USB in a burst, all at once. While the first command is being executed the rest are decoded and buffered. When the first move finishes the Hs-20USB transmits an "a". When the host computer receives the "a" it generates a signal on its parallel port to open the pneumatic valve. Meanwhile, the HS-20USB has begun the reverse 45 degree move.

### **AR - Address Read**

Immediate Command. This command reads the value of the address switch and stores the value on the stack.

### **CR <Ramp> - Checksum Ramp**

(Immediate) This command calculates and returns the checksum for the specified ramp table.

### **D <Int> - Delay**

(Buffered) Delays specified number of milliseconds during buffered command processing. Example: You must move parts to a specific location, allow time for them to be processed, and then move them again:

```
v3 1 1600 0 800 2 400 ; First move
D 1000                ; Delay exactly one second
v2 0 3000 1 1500      ; Second move
```

### **DD <Prog> - Data Dump**

(Immediate) Dump the contents of program/data space Prog to the serial/USB port. All 127 data values are dumped as 16 bit hex numbers. See DL command for example.

### **DL <Prog> <Count>- Data Load**

(Immediate) Load program/data space Prog with list of numbers to follow, where Count indicates how many numbers are to be expected. A maximum of 127 is permitted. Example: Load program/data space 7 with the following trigger points (see Trigger command) 2, 3, 100, 245, 300, and 0:

```
DL 7 6                ; Load program space 7 with following 6 numbers
2
3
100
245
300
0
DD 7                  ; Confirm by dumping; CyberVec output will be as follows:
                        ; 0002
                        ; 0003
                        ; 0064
                        ; 00F5
                        ; 012C
                        ; 0000
```

## **DOB - Dump Output Buffer**

(Immediate) In multi-drop mode, command responses are stored in a buffer and are not output to the serial port, as these characters would otherwise be lost. When you select an indexer then issue this command, and all characters which are in the buffer are then transmitted to the host.

## **DR <Ramp> <Count> - Download Ramp**

(Immediate) Where Ramp indicates which ramp is being downloaded, and Count specifies the number of elements (integers) that will be downloaded in the subsequent list. The data for this command must be in a specified format. The first number is the pre-scale value. This is followed by a 0 and then the ramp values. After the ramp values are sent a terminating zero (0) is sent.

## **EN - Echo No**

(Immediate) Terminates echo mode. Following this command, received characters will no longer be echoed to the serial/USB port. All commands that return data (AIC, AKC, etc.) will still return their respective data. See also EY.

Example: You are using a program to send commands to CyberVec and do not want transmitted characters echoed back to the serial port. At some later time you find a problem and wish to test it manually. You would like to see your own typing so you must turn the echo function back on.

```
EN                ; Set No Echo Mode during PC to HS-20USB comm
V1 0 800          ; Move etc.
.
.
.
EY                ; Set Echo Mode during operator interaction
V2 0 800 1 400    ; Move
AK^               ; Acknowledge
```

## **EY - Echo Yes**

(Immediate) Enables echo mode. Following this command all received characters will be echoed back to the serial/USB port. See EN (Echo No) for example.

## **FL - Flush Buffer**

(Immediate) Clears the instruction buffer. Does not affect the command that is currently being executed. This command also resets to zero the absolute target position registers for the X=,Y=,Z=, and U= commands. See AB (abort) for example.

## **PC <Prog> - Program Checksum**

(Immediate) This command returns the checksum of the specified program. See also PV (Program Verify).

## **PD <Prog> - Program Dump**

(Immediate) This Command dumps the specified program to the serial/USB port so that the user can verify the contents of program locations.

## **PL <Prog> - Program Load**

(Immediate) This command loads all following data into the specified program data area. The maximum number of bytes allowed in a program area is 250. A program must be terminated by the period '.' character.

Example: An application uses a sequence of moves several times and it is decided to store them in a program space. The program is verified and a checksum recorded to verify the program is correct on future units.

```
PL 1                ; Command to load program into space 1
V1 0 1000           ; The program itself
V2 0 -1000 1 -1000
R 2000
V1 1 5000
R 1000
.                  ; Program terminator character
PD 1                ; Dump program to serial/USB port
!PC 1              ; Also output checksum to serial/USB port in print mode
```

## **PO - Pop the Stack**

Immediate Command. No arguments. This command pops a value from the stack. This value is not returned, it is simply removed from the stack; thrown away.

## **PU <int> - Push Value onto Stack**

(Immediate) Pushes int onto the stack.

## **PV <Prog> - Program Verify**

(Immediate) Compare the recomputed checksum of the program in space Prog with its stored checksum. If the results match, then the program is most likely intact and executable, and a TRUE is returned to the stack. Example:

```
PV 3                ; verify program in space 3
IF ^ { PX 1 }       ; if program is OK then execute program 1
OSS "Program 3 has bad checksum" ; otherwise output err message
.                  ; exit (stop running) application program
```

## **PX <Prog> - Program Execute**

(Immediate) Execute program in specified space, under the assumption that a valid CyberVec program has been previously stored there.

Example: We have previously installed a program in space 1:

```
v1 0 1000          ; start of program -- a total of three moves
v2 0 -1000 1 1000
v2 0 1000 1 -1000
.                  ; required program terminator
```

To start execution from interactive command mode we send the following command to the HS-20USB:

```
PX 1
```

### QF - Query Flags

(Immediate) Returns the master status byte wherein a 1 bit indicates an internal condition which existed, however briefly. Using this command resets all bits back to zero until a condition sets them again so if you must test for multiple bits you must save the value returned by QF into a variable for re-use.

Bit	Meaning
0	Instruction FIFO was full on a write attempt. This is not an error, but means the commands are being sent faster than they can be executed or queued.
1	Character FIFO has over-flowed and data has been lost. This is an error, which may cause subsequent commands to be misinterpreted. Your program did not observe the XON-XOFF protocol.
2	Step over run flag, indicates that the commanded step rate was greater than the rate at which CyberVec was capable of running.
3	An illegal instruction was sent to CyberVec. If you don't think that you sent an illegal command, perhaps there was a missing argument, or illegal argument to the instruction, or a communications error.
4	A limit switch closed during a previous move. This signals can be read to determine if there was an over-travel by any axis during a move.
5	Internal Error
6	Internal Error
7	Stall Detect true when set to 1.

### QI - Query Instruction Count

(Immediate) This command returns the count of buffered commands awaiting execution.

### QS - Query Sense/Limit Inputs

(Buffered) This command echoes the status of the limit switch checking function of CyberVec. If a limit switch has been closed this function will return a data mask representing which axis limit a switch closed on. An integer is returned with one bit set for each axis, with axis 0 in the least significant bit, axis 1 in the next least significant bit, and so on. The bit value does not indicate whether it was the CCW or CW limit which was closed. Using this command to read this data clears this data. This command may be used after QF in which a set bit 4 indicates that 'a' limit switch has closed but does not tell you which one.

## **QV - Query Version Number**

(Immediate) Returns the CyberVec version number in a special format where the high byte of the integer contains the major version number and the low byte contains the minor version number in BCD format.

Example: An upgraded host PC software application can provide a special new feature on the machine if the HS-20USB system which controls it has CyberVec firmware with version 4.32 or later. The host computer can determine which version firmware is in the control system without removing the machine electronics panel for inspection of the EPROM label by downloading the following command for execution:

**!QV**

Assuming that the CyberVec version number is 4.33, the above command will cause the HS-20USB to transmit "0433" via the serial/USB port to the host PC, thus indicating that the new feature can be implemented. Note the "!" character preceding the command, which causes the return value to be output to the serial/USB port as decimal character string rather than being put on the stack as a binary value.

## **RES <Area> - Restore RAM**

(Immediate) Restores the specified RAM area from flash memory, where Area = 1 specifies all 128 program spaces; 2 specifies the user ramps; and 3 specifies the named variables. A "D" character (for "done") is automatically transmitted via the serial communications link when the command is completed. Note that all three of these RAM areas are automatically restored during power-up. See also SAV.

## **RST - Reset**

(Immediate) This command resets the HS-20USB microcontroller by stopping strobes to the watchdog timer. There is a short delay after this instruction as the system re-initializes. If a valid CyberVec program 0 is then detected it will be automatically executed.

## **SAV <Area> - Save RAM**

(Immediate) Saves the specified RAM area to flash memory, where Area = 1 specifies all 128 program spaces; 2 specifies the user ramps; and 3 specifies the named variables. A "D" character (for "done") is automatically transmitted via the serial communications link when the command is completed. Inasmuch as flash memory supports only a limited number of write cycles (though this number is in the millions), **the SAV command should not be embedded in a CyberVec program loop.**

## **ST - Self Test**

(Immediate) Initiates an HS-20USB self test. This command should only be issued in interactive terminal mode, and requires a special self-test loopback adapter. It will destroy the RAM contents by overwriting it with test patterns.

## **WC - Wait For Commands to Finish**

(Immediate) This command waits for buffered command processing to be completed, thus allowing synchronization between the host PC and the motion control subsystem.

Example: An application requires that a pneumatic solenoid be energized after a the motor in the control system has reached the point commanded. The following program segment illustrates one way to do this:

```
V2 0 3000      ; Send motor move
WC             ; wait for move to complete
OB 1 8 1 0     ; Output 1 low (0) bit to pin 8 of J201
               ; in order to energize solenoid opto-relay
```

## **WOH <Type> <Mask> - Wait On High**

(Immediate) This command waits for any of the specified digital input pins to go high before executing the next command. This command works only with the J201 limit inputs, i.e., Type must be set to 1. Mask is a bit-wise value specifying which pins are to be tested (1's) and which are to be ignored (0's). The least significant bit of Mask corresponds to J201 pin 11; thus, a Mask value of %07 would wait until any of the limit inputs for motor 0 and gone high (J201 pins 11,12,13) before continuing with the next command. See also WOL, WPH, and WPL.

## **WOL <Type> <Mask> - Wait On Low**

(Immediate) This command waits for any of the specified digital input pins to go low before executing the next command. This command works only with the J201 limit inputs, i.e., Type must be set to 1. Mask is a bit-wise value specifying which pins are to be tested (1's) and which are to be ignored (0's). The least significant bit of Mask corresponds to J201 pin 11; thus, a Mask value of %07 would wait until any of the limit inputs for motor 0 and gone high (J201 pins 11,12,13) before continuing with the next command. See also WOH, SPH, and WPL.

## **WPH <Type> <Pin> - Wait For a Pin to Go High**

(Immediate) This command waits for the specified digital input pin to go high before executing the next command.

<Type> - Indicates which connector or method of reading connector

1 = J201 connector  
2 = J301 connector

<Pin> - Specifies the pin (1 - 26) to test.

Example: You require a system to wait for a go signal from a PLC before initiating a move:

```
WPH 1 16      ; wait for signal on pin 16
               ; of J201 to go to +5 volts
V1 0 5000     ; Move motor #0, 5000 steps
```



### **WPL <Type> <Pin> - Wait For a Pin to Go Low**

(Immediate) This command waits for the specified digital input pin to go low before executing the next command. See also WPH.

<Type> - Indicates which connector or method of reading connector

1 = J201 connector  
2 = J301 connector

<Pin> - Specifies the pin (1 - 26) to test.

## Internal Commands

The commands in this section directly affect internal registers. It is highly recommended that the general user not use these commands due to the unforeseen effects they could have on the CyberVec system. These commands are more subject to change than the standard commands. Most of these commands have to do with the details of step motor timing control.

With ramping enabled, the rate specified in the R (Rate) command is the maximum stepping rate. The start-stop rate is determined by the characteristics of the ramp table. The internal ramp table characteristics may be determined by the QT (not yet implemented) command. You may generate your own ramp table in the HS-20 RAM by using the GR (not yet implemented) command.

Commands permit direct immediate control over the rate of the system step rate. You may even, to an extent, turn off ramping and use the RI, RU, RD, and QR commands to do your own ramping. This requires a considerable understanding of some technical aspects of the internal workings of the HS-20USB CPU/TIMER, and is not recommended for most applications.

RI, RU, RD rate commands deal directly with the Z8 counter timer to determine the rate. You must be knowledgeable about the Z8 hardware in order to make precise use of this feature. This use is not recommended and may be prohibited in future releases.

$PRE1 = \text{INT}(7200/\text{RATE}) + 1$

$T1 = (921600/\text{PRE1})/\text{RATE}$  (T1 WILL BE NEAR 128)

To combine these values into one 16 bit integer:

$\text{CTC} = \text{PRE1} * 256 + T1$  (CTC must be = 16383 and "RI CTC ")

For rate sensitive applications, these features can permit speed adjustments of better than 1% through much of the speed range of the High Stepper System.

### ID - Immediate Disable

(Immediate) Disables step interrupt. Effect dependent on instruction which was under execution at the time.

### IE - Immediate Enable

(Immediate) Enables step interrupt. Effect dependent on instruction which was under execution at the time.

### QR - Query Rate

(Immediate) Immediately on receipt, the current values in the PRE1 and T1 register are transmitted back as a hex word with the 6 bit value in PRE1 as the MSB.

### QT - Query Ramp Table Characteristics

(Immediate) Returns 4 hex digits, the first two being the prescale value defined in the ramp table (used on start up) and the second two digits being the highest value in the ramp table, which is used at top speed.

### **RD - Rate Down**

(Immediate) Increments by one the timer constant in T1, resulting in slightly slower rate. Inhibited if T1 is outside the range of 245-10.

### **RH <int> - Rate Home**

(Immediate) Set the rate at which the system moves a motor out from an axis home limit switch after having engaged it. This rate must be within the start stop rate of your step motor/mechanical system, which is usually between 100 and 1000 steps per second maximum. Actually the argument is in prescaler format. The two low bits must be set to 1's. The high six bits determine the move-out rate, with the fastest rate being a small number and the slowest rate being all one bits. 'RH %FF' is slowest and RH %13 is much faster. RH %07 would be the fastest but is probably beyond the start stop rate of your motors and would not work. Selecting different ramps [SR 10 R 5000 for example] may affect the speed you achieve with a particular value. This command will be available soon with a normal steps per second argument; will change soon.

### **RI <int> - Rate Immediate**

(Immediate) Applies the MSB of the hexadecimal argument to PRE1 and the LSB of T1. CAUTION: For the high and low bytes, 0=64 and 0=256 respectively.

### **RS <int> - Rate Slew**

(Immediate) Sets the minimum T1 value. The motor will ramp up or down to attain the speed set by xx. Smaller xx values result in higher speeds. Use this command where dynamic speed control with ramping is required. RS 0 is a special case, whereby a vector in progress is ramped down to the start-stop speed, then terminated. An additional side effect of this is that the firmware will continue to gobble up instructions from the instruction fifo but will in effect not execute the movement instructions in it. The behavior of this side effect is subject to change in future releases.

### **RU - Rate Up**

(Immediate) Decrements by one the timer constant in T1, resulting in slightly faster rate. Inhibited if T1 is outside the range of 245-10.

# APPENDIX A

## Installation of USB Driver Software on Host PC

1. Go to the "Support" page of the CyberPak web site [www.cyberpakco.com](http://www.cyberpakco.com).
2. With the assumption that you are running Windows XP or Windows 2000, click on "HS-20USB XP/2000 Driver Software". Your browser should then give you the opportunity to download the target .ZIP file, which is named HS-20USB\_XP\_20000\_DRIVERS.ZIP.
3. Exit from your browser and confirm that this file was correctly downloaded (probably to your desktop). It should have an unzipped size of approximately 380 KB.
4. Create a folder on your PC (for example, C:\HS-20USB\_DRIVERS), and unzip the contents of the downloaded folder to it. You should end up with a folder containing approximately 16 files, the first of which is "CDM 2.00.00 Release Info.doc". We will refer to this as the "Driver Folder". We will actually be loading TWO drivers from this folder -- one for the USB link itself, and a second which provides the "virtual" COM port.
5. Plug the USB cable from the host PC into the CyberPak electronics. It is NOT necessary to have the CyberPak electronics powered up at this point inasmuch as the USB interface portion of the CyberPak electronics is powered via the USB cable itself.
6. The Windows "New Hardware Wizard" will pop up. Select "No, not this time" to inform it that you wish to locate the appropriate drivers yourself. Click "Next".
7. In the next window, select "Install from a list or specific location (Advanced)", then click "Next".
8. In the next window, select "Search for the best driver in these locations", then click "Browse".
9. In the next window, browse to the "Driver Folder", select it, then click "OK".
10. Upon return to the previous window, the path to the driver folder should now be displayed. Click "Next".
11. Windows will find the first of the two drivers it must load, and will probably display a warning message to the effect that the driver has not passed Microsoft certification. If so, press "Continue Anyway".
12. Windows will now display a screen showing its progress in loading the driver.
13. When the driver has been completely loaded, Windows will display a final Window. Click "Finish".
14. Repeat steps 6 through 13 to load the second driver.
15. You should now find yourself back at your Windows desktop.
16. To confirm that a "virtual" COM port has been created, and to determine its identity, first go to the Windows Control Panel
17. Select "Classic Mode" to view the Control Panel if not already in that mode.
18. Click twice on the "System" icon.
19. Select the "Hardware" tab on the next window.
20. Select "Device Manager" from the next menu. Windows will now build a list of the types of devices on your system.
21. Click on the "+" sign next to the "Ports (COM & LPT)" category. Windows will display a drop-down list of such devices.
22. One of the "devices" in this list should be "HS-20USB (COMn)", where "n" is some integer value (typically 3). **This port may be used by any PC application, just as if it were a real serial port, for communicating with the DPAK.**
23. It is possible to change the number assigned to this virtual port in order to match that required by an existing application, as long as the desired number does not correspond to an actual COM port. Start by RIGHT clicking on the "HS-20USB (COMn)" identifier.
24. Select "Properties" from the subsequent menu.
25. Select the "Port Settings" tab in the next window.
26. Select the "Advanced..." option in the next window.

27. In the next window, use the "COM Port Number:" scroll bar to select the desired new COM port number.
28. Click "OK" to exit this window while preserving changes.
29. Click "OK" to exit previous window while preserving changes.
30. Close the Device Manager window.